

Dynamix UM-SN Ver.2 User Manual

Version 1.03

Tables of Contents

| | | |
|----------|--|-----------|
| 1 | INTRODUCTION | 4 |
| 1.1 | MODELS | 4 |
| 1.1.1 | E1 interface model..... | 4 |
| 1.1.2 | Serial (V.35) interface model..... | 4 |
| 1.1.3 | Ethernet interface model | 4 |
| 1.1.4 | Multi-interfaces model..... | 4 |
| 1.2 | FEATURES..... | 5 |
| 1.3 | SPECIFICATION | 5 |
| 1.4 | APPLICATIONS | 8 |
| 2 | GETTING TO KNOW ABOUT THE SHDSL NTU | 9 |
| 2.1 | FRONT PANEL | 9 |
| 2.1.1 | E1 interface model..... | 9 |
| 2.1.2 | Serial interface model..... | 9 |
| 2.1.3 | Ethernet interface model | 9 |
| 2.1.4 | Multi-interfaces model..... | 10 |
| 2.2 | REAR PANEL | 12 |
| 2.2.1 | E1 Interface Model..... | 12 |
| 2.2.2 | Serial (V.35) Interface Model..... | 13 |
| 2.2.3 | Ethernet Interface Model | 14 |
| 2.2.4 | Multi-interfaces Model..... | 15 |
| 2.3 | INSTALLATION..... | 16 |
| 2.3.1 | For E1 Interface | 17 |
| 2.3.2 | For Serial Interface | 18 |
| 2.3.3 | For Ethernet Interface | 19 |
| 3 | CONFIGURATION WITH KEYPAD AND LCD..... | 21 |
| 3.1 | KEY PADS..... | 21 |
| 3.2 | MAIN MENU TREE..... | 22 |
| 3.3 | MENU TREE FOR [SHOW STATUS] | 24 |
| 3.4 | MENU TREE FOR [SHOW STATISTICS] | 28 |
| 3.5 | MENU TREE FOR [SYSTEM SETUP] | 31 |
| 3.5.1 | Sub-Menu tree for SETUP E1 Interface..... | 35 |
| 3.5.2 | Sub-Menu tree for SETUP SERIES Interface..... | 39 |
| 3.5.3 | Sub-Menu tree for SETUP Ethernet Interface..... | 42 |
| 3.5.4 | Application of Multi-interfaces..... | 43 |
| 3.6 | MENU TREE FOR [REBOOT SYSTEM] | 49 |
| 3.7 | MENU TREE FOR [SYSTEM DISGNOSTIC] | 50 |
| 3.7.1 | Loopback Test..... | 52 |

| | | |
|----------|---|------------|
| 3.7.2 | BER Test | 55 |
| 3.8 | PARAMETERS TABLE | 56 |
| 3.8.1 | E1 Interface Model..... | 56 |
| 3.8.2 | Serial Interface Model..... | 56 |
| 3.8.3 | Ethernet Interface model | 57 |
| 3.8.4 | Multi-interface model--E1 Interface..... | 57 |
| 3.8.5 | Multi-interface model--Serial Interface | 58 |
| 3.8.6 | Multi-interface model--Ethernet Interface..... | 58 |
| 3.8.7 | Multi-interface model--E1+Serial Interface | 59 |
| 3.8.8 | Multi-interface model--E1+Ethernet Interface..... | 60 |
| 4 | CONFIGURATION WITH CONSOLE PORT..... | 61 |
| 4.1 | LOGIN PROCEDURE | 61 |
| 4.2 | WINDOW STRUCTURE..... | 63 |
| 4.3 | MENU COMMANDS | 64 |
| 4.4 | MAIN MENU SUMMARY..... | 65 |
| 4.5 | [SETUP] CONFIGURATION | 66 |
| 4.5.1 | Configure Interface | 70 |
| 4.5.2 | Configure SHDSL parameters | 72 |
| 4.5.3 | Configure E1 parameters..... | 78 |
| 4.5.4 | Configure Serial parameters..... | 87 |
| 4.5.5 | Configure Ethernet parameters | 95 |
| 4.5.6 | Enable and Disable Remote configuration..... | 99 |
| 4.5.7 | Restore factory default setting..... | 100 |
| 4.6 | [STATUS] VIEW THE SYSTEM STATUS | 102 |
| 4.6.1 | Show SHDSL Status..... | 103 |
| 4.6.2 | Show Interface Status | 105 |
| 4.6.3 | Show Current Performance..... | 106 |
| 4.6.4 | View the Local and remote Statistics..... | 108 |
| 4.6.5 | Clear Channel Statistics..... | 113 |
| 4.7 | [SHOW] VIEW SYSTEM CONFIGURATION | 114 |
| 4.7.1 | Show general Interface | 114 |
| 4.7.2 | Show configuration in listing format..... | 116 |
| 4.7.3 | Show configuration in command script | 119 |
| 4.8 | [REBOOT] REBOOT THE SYSTEM | 122 |
| 4.9 | [DIAG] DIAGNOSTIC – LOOPBACK AND BER TEST | 123 |
| 4.9.1 | Loopback test | 124 |
| 4.9.2 | BER Test | 125 |
| 4.10 | [UPGRADE] FIRMWARE UPGRADE..... | 127 |
| 4.11 | [EXIT] EXIT THE SYSTEM | 133 |
| 5 | APPENDIX..... | 135 |

| | | |
|------|---|-----|
| 5.1 | ABBREVIATION | 135 |
| 5.2 | SERIAL INTERFACE PIN ASSIGNMENTS | 138 |
| 5.3 | V.35 DB25(M) TO M.34(F) ADAPTOR CABLE | 140 |
| 5.4 | X.21 DB25(M) TO DB15(F) ADAPTOR CABLE | 142 |
| 5.5 | CONSOLE CABLE..... | 144 |
| 5.6 | E1 BALANCE CABLE | 146 |
| 5.7 | E1 UNBALANCE CABLE | 147 |
| 5.8 | ETHERNET CABLE..... | 148 |
| 5.9 | DSL CABLE | 149 |
| 5.10 | POWER CORD..... | 150 |
| 5.11 | ILLUSTRATION OF LOOPBACK CONNECTION DEVICE (E1) | 151 |
| 5.12 | ILLUSTRATION OF LOOPBACK CONNECTION DEVICE (SERIAL) | 152 |

1 Introduction

1.1 Models

The UM-SN VER.2 NTU offers three different interfaces (E1, Serial and Ethernet) connected customers to high-speed TDM services. This series has four models on the following:-

1.1.1 E1 interface model

It offers two different ways have connected customers to high-speed TDM services with two G.703 E1 interfaces (Balance 120Ω RJ45 jack and Unbalance 75Ω dual BNCs). The G.703 interface can carry 64kbps to 2.048Mbps.

1.1.2 Serial (V.35) interface model

It offers customers premises has high-speed TDM services with a DB25 interface. The industry standard DB25 interface can be configured as a V.35/RS530 or V.36/X.21 connection. The DB25 connection can transfers data up to 2.304Mbps.

1.1.3 Ethernet interface model

It offers customers premises has high-speed TDM services with a LAN interface. The industry standard LAN interface can detect a 10Mbps or 100Mbps connection automatically.

1.1.4 Multi-interfaces model

It offers customers premises have three types interface: E1 interface (balanced 120Ω RJ48C jack and unbalanced 75Ω dual BNCs), V.35 interface (DB25 female connector) and Ethernet interface (RJ-45 connector). You can select five type interfaces according to your application: (a) E1 interface only, (b) Series interface only, (c) Ethernet interface only, (d) E1 and Serial interface come together and (e) E1 and Ethernet interface come together.

They can be configured and managed via EOC, or menu-driven VT100 compatible Asynchronous Terminal Interface, either locally or remotely.

The UM-SN VER.2 NTU is equipped with an auto rate capability that identifies the maximum line rate supported by the copper loop. This powerful automatic configuration capability makes installation and service provisioning simple and painless. Further flexibility is provided in the ability to manually set the maximum NTU speed at different levels for different customer-tailored service offerings.

1.2 Features

- ✓ Standard UM-SN VER.2 (ITU G.991.2) supports improved reach/speed and greater interoperability
- ✓ Fast and cost-effective provisioning of traditional frame relay (FR or T-HDLC) or TDM leased line services
- ✓ User existing copper loop infrastructures
- ✓ Can operate back to back connection
- ✓ Efficient single wire pair usage
- ✓ Up to 2.312Mbps symmetric service bit rate
- ✓ Auto rate installation maximizes data rate based on loop conditions
- ✓ Auto configuration wetting current to protect SHDSL line
- ✓ Local management interface with LCD display
- ✓ Remote line loopback
- ✓ SHDSL Line performance monitoring (Data Rate and SNR)
- ✓ Raw and per time interval statistics
- ✓ Bandwidth guaranteed transmission equipment
- ✓ Remote firmware upgrade

1.3 Specification

WAN Interface

- Line Rate: SHDSL per G.991.2
- Coding: trellis coded pulse amplitude modulation (TCPAM-16)
- Support: Annex A(ANSI) and Annex B(ETSI)
- Payload rates: 64kbps to 2.304Mbps (N x 64kbps N=1 to 36) for Serial and Ethernet interface
64kbps to 2.048Mbps (N x 64kbps N=1 to 32) for E1 interface
- Connection: RJ-45 jack (2-wire or 4-wire)
- Impedance: 135 ohms

G.703 Interface (as E1)

- Connection: RJ-45 for balanced 120Ω E1 cable
- Connection: BNC for unbalanced 75Ω E1 cable
- Line Rate: 2048KHz +/- 50ppm
- Framing: PCM30/30C/31/31C and Unframed
- Data Rate: 64Kbps to 2.048Mbps (Nx64Kbps , N=1 to 32)
- Operation: Full E1 and Fractional E1

SERIAL Interface (as V.35)

- Connection:DB-25(F)
- Payload rates: Up to 2.304Mbps (N=1 to 36)
- Support RS-530, V.35 or V.36/X.21

LAN Interface (as Ethernet)

- Single Ethernet Interface
- 10/100Mbps Half/Full Duplex, Auto-sensing, Auto-Crossover
- Up to 2048 MAC address learning

DSL Timing

- Internal
- From E1 Recovery (as E1)
- From DTE (as V.35 and Ethernet)

Performance Monitoring

- ES, SES, UAS, LOSW, Alarms, Errors

Loopback Tests (for E1 and V.35 interface only)

- Digital Local Loopback
- Digital Loopback
- Remote Line Loopback
- Remote Payload Loopback
- Far-end Line Loopback
- Far-end Payload Loopback
- V.54(For V.35 interface only)
- Build-in 2047 bit ($2^{11}-1$) BER tester



Management

- Configuration with keypads and LCD display
- Console port (RJ45)
- Support firmware upgradeable

Physical/Electrical

- Dimensions: 19.8 x 4.6 x 16.8 cm
- Input: For AC power input version 90~240VAC with 50~60Hz
For DC Power input version -48VDC
- Power Consumption: 10W Max
- Operation temperature: 0 to 50°C
- Humidity: Up to 95% (non-condensing)
- External screw for frame grounding

1.4 Applications




2 Getting to know about the UM-SN Ver.2 NTU


This chapter shows the front and rear panel and how to install the hardware.

2.1 Front Panel


2.1.1 E1 interface model




2.1.2 Serial interface model



2.1.3 Ethernet interface model



2.1.4 Multi-interfaces model



Front panel can be separated into three parts: LCD display, LED indicator and Keypads.
 The LCD display can show the status and configuration of device. The local management interface will be done by keypads with this LCD display.
 The purpose of key pads is to configure the setting or selecting of function on this SHDSL NTU.

The following table describes the LEDs' function of device.


| LED | | Color | Action | Description |
|------------|------------|--------|--------|-----------------------------------|
| PWR | | Green | On | Power is on. |
| | | | Off | Power is off. |
| ALM | | Red | On | System loss. |
| | | | Off | System is working nomarally. |
| TST | | Yellow | On | System is testing for connection. |
| | | | Off | System is working nomarally. |
| DSL | SYN | Green | On | SHDSL line is connected. |
| | | | Blink | Data transmit in SHDSL line. |
| | | | Off | SHDSL line is dropped. |
| | ERR | Red | Blink | Error second occurs. |
| | | | Off | No error second. |
| | LPB | Yellow | On | Loopback is on. |
| | | | Off | Loopback is off. |
| E1 | SYN | Green | On | E1 line is connected. |
| | | | Off | E1 line is dropped. |
| | ERR | Red | Blink | There are error seconds. |
| | | | Off | There is not any error second. |
| | LPB | Yellow | On | Loopback is on. |
| | | | Off | Loopback is off. |

| | | | | |
|---------------|-------------|-------|-------|------------------------------------|
| Serial | TD | Green | On | Data transmit in V.35. |
| | | | Off | No data transmit in V.35. |
| | RD | Green | On | Data receive in V.35. |
| | | | Off | No data receive in V.35. |
| | ERR | Red | Blink | Error second occurs. |
| | | | Off | No error second. |
| ETH | LINK | Green | On | Data transmit in Ethernet. |
| | | | Off | No data transmit in Ethernet. |
| | 100M | Green | On | Data receive in 100M. |
| | | | Off | No data receive in 100M. |
| | COL | Red | Blink | Error collision occurs. |
| | | | Off | No error collision. |
| Mode | E1 | Green | Blink | E1 Data transmit and receive |
| | | | On | E1 cable connected |
| | | Red | On | No E1 cable connected |
| | SER | Green | Blink | Serial Data transmit and receive |
| | | | On | DTE Connected |
| | | Red | On | DTE Disconnect |
| | ETH | Green | Blink | Ethernet Data transmit and receive |
| | | | On | Ethernet cable connected |
| | | Red | On | No Ethernet cable connected |

2.2 Rear Panel


2.2.1 E1 Interface Model

AC power input version



The rear panel of this model is including power switch, AC power socket, RJ-45 console, G.703 RJ-48C jack or BNC jack for transmitting and receiving and RJ-45 for SHDSL from left to right.

DC power input version




The rear panel of this model is including power switch, DC power socket, RJ-45 console, G.703 RJ-48C jack or BNC jack for transmitting and receiving and RJ-45 for SHDSL from left to right.

Connector Description

| | |
|------------|--|
| ON | Power switch. Press 1 for turn on and press 0 for off |
| 90~240V AC | IEC-320 C6 AC input connector. It has power adapting function from 90V to 240V |
| -48V GND | DC power input connector (-48V) |
| CONSOLE | RJ-45 for system configuration and maintenance |
| G.703 | RJ-48C for 120Ω E1 connection with PABX (Private Automatic Branch Exchange) or E1 Router |
| TX | BNC for 75Ω E1 transmitting |
| RX | BNC for 75Ω E1 receiving |
| SHDSL | RJ-45 for DSL connection |


2.2.2 Serial (V.35) Interface Model

AC power input version



The rear panel of this model is including power switch, AC power socket, RJ-45 for console cable, DB-25(Female) for serial and RJ-45 for SHDSL from left to right.

DC power input version




The rear panel of this model is including power switch, DC power socket, RJ-45 for console cable, DB-25(Female) for serial and RJ-45 for SHDSL from left to right.

Connector Description

| | |
|------------|--|
| ON | Power switch. Press 1 for turn on and press 0 for off. |
| 90~240V AC | IEC-320 C6 AC input connector. It has power adapting function from 90V to 240V |
| -48V GND | DC power input connector (-48V) |
| CONSOLE | RJ-45 for system configuration and maintenance |
| SERIAL | DB-25(F) for RS-530 and V.35 or X.21 (with adaptor cable) |
| SHDSL | RJ-45 for DSL Connection |


2.2.3 Ethernet Interface Model

AC power input version



The rear panel of this model is including power switch, AC power socket, RJ-45 for console cable, LAN for Ethernet cable and RJ-45 for SHDSL from left to right.

DC power input version




The rear panel of this model is including power switch, DC power socket, RJ-45 for console cable, LAN for Ethernet cable and RJ-45 for SHDSL from left to right.

Connector Description

| | |
|------------|---|
| ON | Power switch. Press 1 for turn on and press 0 for turn off. |
| 90~240V AC | IEC-320 C6 AC input connector. It has power adapting function from 90V to 240V. |
| -48V GND | DC power input connector (-48V) |
| CONSOLE | RJ-45 for system configuration and maintenance. |
| ETH | RJ-45 LAN port for Ethernet cable |
| SHDSL | RJ-45 for DSL Connection |


2.2.4 Multi-interfaces Model

DC power input version



The rear panel of this model is including power switch, AC power socket, RJ-45 for console cable, LAN for Ethernet cable, G.703 RJ-48C or BNC jacks for transmitting and receiving, DB-25(Female) for serial and RJ-45 for SHDSL from left to right.

DC power input version



The rear panel of this model is including power switch, DC power socket, RJ-45 for console cable, LAN for Ethernet cable, G.703 RJ-48C or BNC jacks for transmitting and receiving, DB-25(Female) for serial and RJ-45 for SHDSL from left to right.

Connector Description

| | |
|------------|--|
| ON | Power switch. Press 1 for turn on and press 0 for off |
| 90~240V AC | IEC-320 C6 AC input connector. It has power adapting function from 90V to 240V |
| -48V GND | DC power input connector (-48V) |
| CONSOLE | RJ-45 for system configuration and maintenance |
| ETH | RJ-45 LAN port for Ethernet cable |
| E1 | RJ-48C for 120Ω E1 connection with PABX (Private Automatic Branch Exchange) or E1 Router |
| SERIAL | DB-25(F) for RS-530 and V.35 or X.21 (with adaptor cable) |
| TX | BNC for 75Ω E1 transmitting |
| RX | BNC for 75Ω E1 receiving |
| DSL | RJ-45 for DSL connection |

2.3 Installation

Note: To avoid possible damage to this router, do not turn on the product before hardware installation.


- ✓ Plug the power cord in the power socket.
- ✓ Plug the console port in console if you want to configure the NTU with VT100 program of NB or PC.
- ✓ Plug the E1 cable (Either 75Ω BNC cables or 120Ω cable) / SERIAL cable / Ethernet cable
- ✓ Plug SHDSL cable
- ✓ Power on

| Model | Interface modes support |
|--------------------------|-------------------------|
| E1 interface model | E1 interface |
| V.35 interface model | V.35 interface |
| Ethernet interface model | Ethernet interface |
| Multi-interfaces model | E1 interface |
| | V.35 interface |
| | Ethernet interface |
| | E1+V.35 interface |
| | E1+Ethernet interface |


Only the Multi-interfaces model can support all five type interfaces.

2.3.1 For E1 Interface

AC power input version




DC power input version




2.3.2 For Serial Interface

AC power input version




DC power input version




2.3.3 For Ethernet Interface

AC power input version



DC power input version



Protective earth:



The marked lug or terminal should be connected to the building protective earth bus.

The function of protective earth does not serve the purpose of providing protection against electrical shock, but instead enhances surge suppression on the DSL lines for installations where suitable bonding facilities exist.

The connector type is M3 machine screw.

Wetting Current:

Wetting current, also known as loop sealing current, is a low-level DC current applied to a loop for the specific purpose of maintaining cable splice integrity by preventing the build-up of oxidation. There has the ability to sink the source wetting current.




Warning! High Voltage. Do not open the housing.

3 Configuration with Keypad and LCD

This chapter provides information about configuration on your UM-SN VER.2 NTU via front panel LCD display and keypads.

3.1 Key Pads

The UM-SN VER.2 NTU is designed by user-friendly configuration and management can using keypads and LCD display on front panel only without computer with VT100 terminal software.



| Key Pad | Description |
|---------|---|
| Exit/- | Return to previous configuration menu. |
| Enter/+ | Skip to next configuration menu or configure this item. |
| L | Select other parameter in the same level menu. |
| R | Select other parameter in the same level menu. |

3.2 Main menu Tree

After turning on UM-SN VER.2 NTU, the LCD display will prompt "SHDSL NTU" and their interface mode. Press **Enter** key to enter. There will display some sub-menu of the following.

E1 interface mode:

```
SHDSL NTU
=====E1=====
```

| |
|----------------------|
| SHOW STATUS |
| SHOW STATISTICS |
| SYSTEM SETUP |
| REBOOT SYSTEM |
| SYSTEM DIAGNOSTIC |

Serial interface mode:

```
SHDSL NTU
=====SERIAL=====
```

| |
|----------------------|
| SHOW STATUS |
| SHOW STATISTICS |
| SYSTEM SETUP |
| REBOOT SYSTEM |
| SYSTEM DIAGNOSTIC |

Ethernet interface mode:

SHDSL NTU

===ETHERNET===

- SHOW
STATUS
- SHOW
STATISTICS
- SYSTEM
SETUP
- REBOOT
SYSTEM

E1 and Serial interface mode:

SHDSL NTU

== E1 + SERIAL ==

- SHOW
STATUS
- SHOW
STATISTICS
- SYSTEM
SETUP
- REBOOT
SYSTEM
- SYSTEM
DIAGNOSTIC

E1 and Ethernet interface mode:

SHDSL NTU

== E1 ETHERNET ==

- SHOW
STATUS
- SHOW
STATISTICS

| |
|----------------------|
| SYSTEM SETUP |
| REBOOT SYSTEM |
| SYSTEM DIAGNOSTIC |

For more detail on those sub-menus, please refer to each chapter.

3.3 Menu tree for [SHOW STATUS]

You can check five kinds mode of status via LCD display.

| |
|----------------|
| SHOW STATUS |
|----------------|

E1 interface mode:

| |
|------------------------|
| STATUS INTERFACE , |
| STATUS SHDSL |
| STATUS E1 |
| STATUS Code Version |

.

V.35 interface mode:

| |
|-------------------------|
| STATUS INTERFACE , |
| STATUS SHDSL |
| STATUS SERIAL |
| STATUS Code Version. |

Ethernet interface mode:

| |
|-------------------------|
| STATUS INTERFACE , |
| STATUS SHDSL |
| STATUS ETHERNET |
| STATUS Code Version. |

E1 and Serial interface mode:

| |
|------------------------|
| STATUS INTERFACE , |
| STATUS SHDSL |
| STATUS E1 |
| STATUS SERIAL |
| STATUS Code Version |

E1 and Ethernet interface mode:

| |
|------------------------|
| STATUS INTERFACE , |
| STATUS SHDSL |
| STATUS E1 |
| STATUS ETHERNET |
| STATUS Code Version |

The next levels of their menus tree are as following:

SHOW STATUS > STATUS INTERFACE

| |
|---------------------|
| STATUS INTERFACE |
|---------------------|

| |
|--------------|
| * INTERFACE* |
|--------------|

SHOW STATUS > STATUS SHDSL

| |
|-----------------|
| STATUS SHDSL |
|-----------------|

| |
|-----------------|
| * MODE * |
| * ANNEX * |
| * LINE RATE * |
| * ATTENUATION * |
| * SNR MARGIN * |
| * TX POWER * |

SHOW STATUS > STATUS E1

| |
|--------------|
| STATUS E1 |
|--------------|

| |
|------------------|
| * SIGNAL FRAME * |
| * LINE CODE * |
| * CHANNEL * |
| * SLOT NUMBER * |
| * FIRST SLOT * |
| * AIS ALARM * |
| * BUILD OUTS * |

SHOW STATUS > STATUS SERIAL

| |
|--------|
| STATUS |
| SERIAL |

| |
|-------------------|
| * INTERFACE * |
| * DATA RATE * |
| * CLOCK * |
| * SERIAL RTS * |
| * SERIAL CTS * |
| * SERIAL DTR * |
| * SERIAL DSR * |
| * SERIAL DCD * |
| * RTS/CTS DELAY * |

SHOW STATUS > STATUS ETHERNET

| |
|----------|
| STATUS |
| ETHERNET |

| |
|--------------|
| *LINK SPEED* |
| *OPERATION* |
| *RATE* |

SHOW STATUS > STATUS CODE VERSION

| |
|--------------|
| STATUS |
| CODE VERSION |

| | |
|--------|------|
| KERNEL | FPGA |
|--------|------|

3.4 Menu tree for [SHOW STATISTICS]

The product can display two kinds of statistics data:

SHDSL statistics data [ES, SES, UAS and LOSW]

Show the current 15 minutes period and 96 previous 15-minutes period of SHDSL performance.

Show the current 24 hours period and 7 previous 24-hours periods of SHDSL performance.

| SHDSL |
|-------|
| ES |
| SES |
| UAS |
| LOSW |

E1 statistics data [ES, SES and UAS]


Show the current 15 minutes period and 96 previous 15-minutes period of E1 performance.

Show the current 24 hours period and 7 previous 24-hours periods of E1 performance.

| E1 |
|-----|
| ES |
| SES |
| UAS |

Abbreviation:

| | |
|-------------|------------------------------|
| ES | Error Second |
| SES | Severely Error Second |
| UAS | Unavailable Second |
| LOWS | Loss of Synchronization word |




Serial Interface

Ethernet Interface

E1 and SERIAL Interface

E1 and Ethernet Interface



3.5 Menu tree for [SYSTEM SETUP]

You can check five kinds mode of setup type via LCD display.

SYSTEM
SETUP

E1 interface mode:

| |
|---------------------------|
| SETUP INTERFACE , |
| SETUP SHDSL |
| SETUP E1 |
| SETUP ALLOW RMT CONFIG |
| SETUP DEFAULT |
| SETUP REMOTE CONFIG |

V.35 interface mode:

| |
|---------------------------|
| SETUP INTERFACE , |
| SETUP SHDSL |
| SETUP SERIAL |
| SETUP ALLOW RMT CONFIG |
| SETUP DEFAULT |
| SETUP REMOTE CONFIG |

Ethernet interface mode:

| |
|---------------------------|
| SETUP INTERFACE , |
| SETUP SHDSL |
| SETUP ETHERNET |
| SETUP ALLOW RMT CONFIG |
| SETUP DEFAULT |
| SETUP REMOTE CONFIG |


E1 and Serial interface mode:

| |
|---------------------------|
| SETUP INTERFACE , |
| SETUP SHDSL |
| SETUP E1 |
| SETUP SERIAL |
| SETUP ALLOW RMT CONFIG |
| SETUP DEFAULT |
| SETUP REMOTE CONFIG |

E1 and Ethernet interface mode:

| |
|----------------------|
| SETUP INTERFACE , |
| SETUP SHDSL |
| SETUP E1 |
| SETUP ETHERNET |

SETUP
SHDSL



| SETUP SHDSL | Selection items |
|----------------------|--|
| SETUP MODE | STU-R, STU-C-INTCLK, STU-C-EXTCLK |
| SETUP ANNEX | A, B |
| SETUP STARTUP MARGIN | DISABLE , 0 to 10 |
| SETUP PSD | R1_ASTM, R2_ASYM, SYM_ENABLE, ASYM_DISBALE |
| SETUP POWER BACK OFF | Disable, Enable |


The following are commonly used acronyms for **SETUP MODE**:

| | |
|--------------|--|
| STU-R | RT side, where the clock source is set to external |
| STU-C-INTCLK | CO side, where the clock source is set to internal |
| STU-C-EXTCLK | CO side, where the clock source is set to external |

3.5.1 Sub-Menu tree for SETUP E1 Interface

SYSTEM SETUP → SETUP E1

SETUP
E1



E1 parameter setting:

| E1 Items | Setting |
|------------|--|
| Channel | FULL PCM31 PCM31C PCM30 PCM30C |
| Code | HDB3 AMI |
| AIS | On Off |
| Build Outs | 120 ohms 75 ohms |

E1 Framer Setting:

| Framer | | Slot Number | First Slot |
|--------|--------------|-------------|------------------------|
| PCM31 | FAS | 1 to 31 | 1 to 31 |
| PCM31C | FAS+CRC4 | 1 to 31 | 1 to 31 |
| PCM30 | FAS+CAS | 1 to 30 | 1 to 31 (can't use 16) |
| PCM30C | FAS+CAS+CRC4 | 1 to 30 | 1 to 31 (can't use 16) |
| FULL | UNFRAMED | | |

Table of number of slots and their first time slot:

| Channel | Number of slots | 1 st slot |
|--------------------|-----------------|----------------------|
| FULL (UNFRAMED) | ----- | ----- |
| PCM31 PCM31C | 31 | 1 |
| | 30 | 1~2 |
| | 29 | 1~3 |
| | 28 | 1~4 |
| | 27 | 1~5 |
| | 26 | 1~6 |
| | 25 | 1~7 |
| | 24 | 1~8 |
| | 23 | 1~9 |
| | 22 | 1~10 |
| | 21 | 1~11 |
| | 20 | 1~12 |
| | 19 | 1~13 |
| | 18 | 1~14 |
| | 17 | 1~15 |
| | 16 | 1~16 |
| | 15 | 1~17 |
| | 14 | 1~18 |
| | 13 | 1~19 |
| | 12 | 1~20 |
| | 11 | 1~21 |
| | 10 | 1~22 |
| | 9 | 1~23 |
| | 8 | 1~24 |
| | 7 | 1~25 |
| | 6 | 1~26 |
| | 5 | 1~27 |
| | 4 | 1~28 |
| | 3 | 1~29 |
| | 2 | 1~30 |
| | 1 | 1~31 |
| PCM30 PCM30C | 30 | 1 |
| | 29 | 1~2 |
| | 28 | 1~3 |
| | 27 | 1~4 |
| | 26 | 1~5 |


| | | |
|--|----|------------|
| | 25 | 1~6 |
| | 24 | 1~7 |
| | 23 | 1~8 |
| | 22 | 1~9 |
| | 21 | 1~10 |
| | 20 | 1~11 |
| | 19 | 1~12 |
| | 18 | 1~13 |
| | 17 | 1~14 |
| | 16 | 1~15 |
| | 15 | 1~15,17 |
| | 14 | 1~15,17~18 |
| | 13 | 1~15,17~19 |
| | 12 | 1~15,17~20 |
| | 11 | 1~15,17~21 |
| | 10 | 1~15,17~22 |
| | 9 | 1~15,17~23 |
| | 8 | 1~15,17~24 |
| | 7 | 1~15,17~25 |
| | 6 | 1~15,17~26 |
| | 5 | 1~15,17~27 |
| | 4 | 1~15,17~28 |
| | 3 | 1~15,17~29 |
| | 2 | 1~15,17~30 |
| | 1 | 1~15,17~31 |

3.5.2 Sub-Menu tree for SETUP SERIES Interface

SYSTEM SETUP → SETUP SERIES


SETUP
SERIAL

7





| Serial Items | Setting |
|--------------|--------------------------|
| INTERFACE | V.35 X.21 (RS-530) |
| Nx64K (Rate) | 1 ~ 36 |
| CLOCK | Normal Inverse |
| RTS | On From DTE |
| CTS | On Off From RTS |
| DSR | On Off From DTR |
| DCD | On Off From DSL |
| DELAY | 0mS 1mS 2mS 3mS |

The handshake signal direction between DCE and DTE



The below diagram shows CTS follow RTS, DSR follow DTR






The RTS delay time is use to control CTS on delay to RTS signal, It is work only for the setting:
CTS follow RTS and RTS follow from DTE

3.5.3 Sub-Menu tree for SETUP Ethernet Interface

SYSTEM SETUP → SET UP ETHERNET


SETUP
ETHERNET



If you set Ethernet **Auto** Negotiation is as Enable, the **Duplex** and **Speed** can't be set up and using auto configuration.

| Ethernet Items | Setting | |
|----------------|----------------------------|-----------------------|
| Rate | 1 ~ 36 | |
| Auto | Disable | Enable |
| Duplex | Full-Duplex Half-Duplex | Auto Configuration |
| Speed | 100M 10M | Auto Configuration |

3.5.4 Application of Multi-interfaces



Case 1 E1(Unframed)+ Serial interface ←-----→ E1(Unframed)+ Serial interface

Case 2 E1(Frame)+ Serial interface ←-----→ E1(Frame)+ Serial interface



Case 3 E1(Frame)+ Ethernet interface ←-----→ E1(Frame)+ Ethernet interface

Case 4 E1(Frame)+ Serial interface ←-----→ E1(Frame)+ Ethernet interface

Table of E1+ Serial interface and E1+Ethernet interface mode on both sides

| E1 interface | | | Serial interface Ethernet interface |
|-----------------|----------------|----------------------|--|
| Channel | Number of slot | 1 st slot | Nx64K (Rate) |
| FULL (UNFRAMED) | ----- | ----- | 1~4 |
| PCM31 PCM31C | 31 | 1 | 1~5 |
| | 30 | 1~2 | 1~6 |
| | 29 | 1~3 | 1~7 |
| | 28 | 1~4 | 1~8 |
| | 27 | 1~5 | 1~9 |
| | 26 | 1~6 | 1~10 |
| | 25 | 1~7 | 1~11 |
| | 24 | 1~8 | 1~12 |
| | 23 | 1~9 | 1~13 |
| | 22 | 1~10 | 1~14 |
| | 21 | 1~11 | 1~15 |
| | 20 | 1~12 | 1~16 |
| | 19 | 1~13 | 1~17 |
| | 18 | 1~14 | 1~18 |
| | 17 | 1~15 | 1~19 |
| | 16 | 1~16 | 1~20 |
| | 15 | 1~17 | 1~21 |
| | 14 | 1~18 | 1~22 |
| | 13 | 1~19 | 1~23 |
| | 12 | 1~20 | 1~24 |
| | 11 | 1~21 | 1~25 |
| | 10 | 1~22 | 1~26 |
| | 9 | 1~23 | 1~27 |
| | 8 | 1~24 | 1~28 |
| | 7 | 1~25 | 1~29 |
| | 6 | 1~26 | 1~30 |
| | 5 | 1~27 | 1~31 |
| | 4 | 1~28 | 1~32 |
| | 3 | 1~29 | 1~33 |
| | 2 | 1~30 | 1~34 |
| | 1 | 1~31 | 1~35 |
| PCM30 PCM30C | 30 | 1 | 1~6 |
| | 29 | 1~2 | 1~7 |
| | 28 | 1~3 | 1~8 |

| | | | |
|--|----|------------|------|
| | 27 | 1~4 | 1~9 |
| | 26 | 1~5 | 1~10 |
| | 25 | 1~6 | 1~11 |
| | 24 | 1~7 | 1~12 |
| | 23 | 1~8 | 1~13 |
| | 22 | 1~9 | 1~14 |
| | 21 | 1~10 | 1~15 |
| | 20 | 1~11 | 1~16 |
| | 19 | 1~12 | 1~17 |
| | 18 | 1~13 | 1~18 |
| | 17 | 1~14 | 1~19 |
| | 16 | 1~15 | 1~20 |
| | 15 | 1~15,17 | 1~21 |
| | 14 | 1~15,17~18 | 1~22 |
| | 13 | 1~15,17~19 | 1~23 |
| | 12 | 1~15,17~20 | 1~24 |
| | 11 | 1~15,17~21 | 1~25 |
| | 10 | 1~15,17~22 | 1~26 |
| | 9 | 1~15,17~23 | 1~27 |
| | 8 | 1~15,17~24 | 1~28 |
| | 7 | 1~15,17~25 | 1~29 |
| | 6 | 1~15,17~26 | 1~30 |
| | 5 | 1~15,17~27 | 1~31 |
| | 4 | 1~15,17~28 | 1~32 |
| | 3 | 1~15,17~29 | 1~33 |
| | 2 | 1~15,17~30 | 1~34 |
| | 1 | 1~15,17~31 | 1~35 |



Case 5 E1 (frame)+ Serial interface <-----> E1 (frame)

Case 6 E1 (frame)+Ethernet interface <-----> E1 (frame)

Table of E1+ Serial interface and E1+Ethernet interface mode on local side and E1 interface on remote side

| E1 interface | | | Serial interface Ethernet interface |
|--------------|-------------------|----------------------------------|--|
| Channel | Number of slot | 1 st slot location | Nx64K (Rate) range |
| PCM31 PCM31C | 31 | 1 | 1 |
| | 30 | 1~2 | 1~2 |
| | 29 | 1~3 | 1~3 |
| | 28 | 1~4 | 1~4 |
| | 27 | 1~5 | 1~5 |
| | 26 | 1~6 | 1~6 |
| | 25 | 1~7 | 1~7 |
| | 24 | 1~8 | 1~8 |
| | 23 | 1~9 | 1~9 |
| | 22 | 1~10 | 1~10 |
| | 21 | 1~11 | 1~11 |
| | 20 | 1~12 | 1~12 |
| | 19 | 1~13 | 1~13 |


| | | | |
|--------------|----|------------|------|
| | 18 | 1~14 | 1~14 |
| | 17 | 1~15 | 1~15 |
| | 16 | 1~16 | 1~16 |
| | 15 | 1~17 | 1~17 |
| | 14 | 1~18 | 1~18 |
| | 13 | 1~19 | 1~19 |
| | 12 | 1~20 | 1~20 |
| | 11 | 1~21 | 1~21 |
| | 10 | 1~22 | 1~22 |
| | 9 | 1~23 | 1~23 |
| | 8 | 1~24 | 1~24 |
| | 7 | 1~25 | 1~25 |
| | 6 | 1~26 | 1~26 |
| | 5 | 1~27 | 1~27 |
| | 4 | 1~28 | 1~28 |
| | 3 | 1~29 | 1~29 |
| | 2 | 1~30 | 1~30 |
| | 1 | 1~31 | 1~31 |
| PCM30 PCM30C | 30 | 1 | 1~2 |
| | 29 | 1~2 | 1~3 |
| | 28 | 1~3 | 1~4 |
| | 27 | 1~4 | 1~5 |
| | 26 | 1~5 | 1~6 |
| | 25 | 1~6 | 1~7 |
| | 24 | 1~7 | 1~8 |
| | 23 | 1~8 | 1~9 |
| | 22 | 1~9 | 1~10 |
| | 21 | 1~10 | 1~11 |
| | 20 | 1~11 | 1~12 |
| | 19 | 1~12 | 1~13 |
| | 18 | 1~13 | 1~14 |
| | 17 | 1~14 | 1~15 |
| | 16 | 1~15 | 1~16 |
| | 15 | 1~15,17 | 1~17 |
| | 14 | 1~15,17~18 | 1~18 |
| | 13 | 1~15,17~19 | 1~19 |
| | 12 | 1~15,17~20 | 1~20 |
| | 11 | 1~15,17~21 | 1~21 |
| | 10 | 1~15,17~22 | 1~22 |
| | 9 | 1~15,17~23 | 1~23 |

| | | | |
|--|---|-------------|------|
| | 8 | 1~15,17~24 | 1~24 |
| | 7 | 1~15, 17~25 | 1~25 |
| | 6 | 1~15, 17~26 | 1~26 |
| | 5 | 1~15, 17~27 | 1~27 |
| | 4 | 1~15, 17~28 | 1~28 |
| | 3 | 1~15, 17~29 | 1~29 |
| | 2 | 1~15, 17~30 | 1~30 |
| | 1 | 1~15, 17~31 | 1~31 |

3.6 Menu tree for [REBOOT SYSTEM]

REBOOT
SYSTEM

While use the REBOOT SYSTEM command, press "ENTER" Key; select "YES" and press "ENTER" Key. You can see the "Reboot..." display. It will return to main menu after the reboot operation is finish.



3.7 Menu tree for [SYSTEM DISGNOSTIC]

SYSTEM
DIAGNOSTIC

System Diagnostic has two functions: Loopback test and BER test.


SYSTEM DIAGNOSTIC → DIAG LOOPBACK

DIAG
LOOPBACK


SYSTEM DIAGNOSTIC → DIAG BER TEST

DIAG
BER TEST

E1 Interface



Serial Interface



3.7.1 Loopback Test

Note : No SYSTEM DIAGNOSTIC menu on Ethernet Interface Model

For E1 Interface model as CO side, there have: local digital, local, remote line, remote payload, farend line and farend payload.

For Serial Interface model as CO side, there have: Local digital, local, remote line, remote payload, farend line, farend payload and V.54.

For E1 Interface model as CPE side, there have: local digital, remote line, remote payload, farend line and farend payload.

For Serial Interface model as CPE side, there have: Local digital, remote line, remote payload, farend line, farend payload and V.54.

If the device haven't connect or under handshake, there will not have farend line, farend payload and V.54.

Definition of **V.54**

An ITU standard (1976) for various loopback tests that can be incorporated into modems for testing the telephone circuit and isolating transmission problems.

Operating modes include local and remote digital loopback and local and remote analog loopback.

Stand alone NTU, no connection with other NTU:

| E1 interface CO side |
|-------------------------|
| Local digital |
| Local |
| Remote line |
| Remote payload |

| Serial interface CO side |
|-----------------------------|
| Local digital |
| Local |
| Remote line |
| Remote payload |

| E1 interface CPE side |
|--------------------------|
| Local digital |
| Remote line |
| Remote payload |

| Serial interface CPE side |
|------------------------------|
| Local digital |
| Remote line |
| Remote payload |



After connection both CO side and CPE side:

| E1 interface CO side |
|-------------------------|
| Local digital |
| Local |
| Remote line |
| Remote payload |
| Farend line |
| Farend payload |

| Serial interface CO side |
|-----------------------------|
| Local digital |
| Local |
| Remote line |
| Remote payload |
| Farend line |
| Farend payload |
| V.54 |

| E1 interface CPE side |
|--------------------------|
| Local digital |
| Remote line |
| Remote payload |
| Farend line |
| Farend payload |

| Serial interface CPE side |
|------------------------------|
| Local digital |
| Remote line |
| Remote payload |
| Farend line |
| Farend payload |
| V.54 |



3.7.2 BER Test

This is the internal Bit Error Rate Tester (BERT) for complete testing of local and remote modem and the link quality without any external test equipment.

This built-in Bit Error Rate Test generator can generate a standard 2047 ($2^{11}-1$) test pattern.

DIAG
BER TEST

BERT 2047
RUN

When the BERT hasn't any Bit Error, it shows zero. Otherwise, it will show some number counter.

RUN(SEC) item shows the time elapsed second count

RUN(SEC): 00001
BIT ERR: 00000

If there is NO SYNC on bit error message, it shows the testing paths haven't connected.

RUN(SEC): 00001
BIT ERR: NO SYNC

Press ENTER key on this display message, it will re-sync again.

BERT 2047
RESYNC

Press ENTER key on this display message, it will show the test real time.

BERT 2047
INFO

If you want to exit the BERT, you can press ENTER key from this display message.

BERT 2047
DISABLE

3.8 Parameters Table

3.8.1 E1 Interface Model

| NTU | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
|-------|----------------|--|
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| E1 | Channel | <input type="checkbox"/> PCM31 <input type="checkbox"/> PCM31C <input type="checkbox"/> PCM30 <input type="checkbox"/> PCM30C <input type="checkbox"/> Unframed |
| | Slot Number | |
| | First Slot | |
| | Code | <input type="checkbox"/> HDB3 <input type="checkbox"/> AMI |
| | AIS | <input type="checkbox"/> Off <input type="checkbox"/> On |
| | Build Outs | <input type="checkbox"/> 75 Ohm <input type="checkbox"/> 120 Ohm |

3.8.2 Serial Interface Model

| NTU | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
|--------|----------------|--|
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| Serial | Interface | <input type="checkbox"/> V.35 <input type="checkbox"/> X.21 |
| | Data Rate | |
| | Clock | <input type="checkbox"/> Normal <input type="checkbox"/> Inverse |
| | RTS | <input type="checkbox"/> On <input type="checkbox"/> From DTE |
| | CTS | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From RTS |
| | DSR | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DTR |
| | DCD | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DSL |
| | Delay | <input type="checkbox"/> 0mS <input type="checkbox"/> 1mS <input type="checkbox"/> 2mS <input type="checkbox"/> 3mS |

3.8.3 Ethernet Interface model

| | | |
|----------|----------------|--|
| NTU | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| Ethernet | Date Rate | |
| | Auto Config | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| | Speed | <input type="checkbox"/> Full <input type="checkbox"/> Half |
| | Duplex | <input type="checkbox"/> 100M <input type="checkbox"/> 10M |

3.8.4 Multi-interface model--E1 Interface

| | | |
|-------|----------------|--|
| NTU | Interface | <input checked="" type="checkbox"/> E1 <input type="checkbox"/> Serial <input type="checkbox"/> Ethernet <input type="checkbox"/> E1+Serial <input type="checkbox"/> E1+Ethernet |
| | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| E1 | Channel | <input type="checkbox"/> PCM31 <input type="checkbox"/> PCM31C <input type="checkbox"/> PCM30 <input type="checkbox"/> PCM30C <input type="checkbox"/> Unframed |
| | Slot Number | |
| | First Slot | |
| | Code | <input type="checkbox"/> HDB3 <input type="checkbox"/> AMI |
| | AIS | <input type="checkbox"/> Off <input type="checkbox"/> On |
| | Build Outs | <input type="checkbox"/> 75 Ohm <input type="checkbox"/> 120 Ohm |

3.8.5 Multi-interface model--Serial Interface

| | | |
|--------|----------------|--|
| NTU | Interface | <input type="checkbox"/> E1 <input checked="" type="checkbox"/> Serial <input type="checkbox"/> Ethernet <input type="checkbox"/> E1+Serial <input type="checkbox"/> E1+Ethernet |
| | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| Serial | Interface | <input type="checkbox"/> V.35 <input type="checkbox"/> X.21 |
| | Data Rate | |
| | Clock | <input type="checkbox"/> Normal <input type="checkbox"/> Inverse |
| | RTS | <input type="checkbox"/> On <input type="checkbox"/> From DTE |
| | CTS | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From RTS |
| | DSR | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DTR |
| | DCD | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DSL |
| | Delay | <input type="checkbox"/> 0mS <input type="checkbox"/> 1mS <input type="checkbox"/> 2mS <input type="checkbox"/> 3mS |

3.8.6 Multi-interface model--Ethernet Interface

| | | |
|----------|----------------|--|
| NTU | Interface | <input type="checkbox"/> E1 <input type="checkbox"/> Serial <input checked="" type="checkbox"/> Ethernet <input type="checkbox"/> E1+Serial <input type="checkbox"/> E1+Ethernet |
| | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| Ethernet | Date Rate | |
| | Auto Config | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| | Speed | <input type="checkbox"/> Full <input type="checkbox"/> Half |
| | Duplex | <input type="checkbox"/> 100M <input type="checkbox"/> 10M |

3.8.7 Multi-interface model--E1+Serial Interface

| | | |
|--------|----------------|--|
| NTU | Interface | <input type="checkbox"/> E1 <input type="checkbox"/> Serial <input type="checkbox"/> Ethernet <input checked="" type="checkbox"/> E1+Serial <input type="checkbox"/> E1+Ethernet |
| | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| E1 | Channel | <input type="checkbox"/> PCM31 <input type="checkbox"/> PCM31C <input type="checkbox"/> PCM30 <input type="checkbox"/> PCM30C <input type="checkbox"/> Unframed |
| | Slot Number | |
| | First Slot | |
| | Code | <input type="checkbox"/> HDB3 <input type="checkbox"/> AMI |
| | AIS | <input type="checkbox"/> Off <input type="checkbox"/> On |
| | Build Outs | <input type="checkbox"/> 75 Ohm <input type="checkbox"/> 120 Ohm |
| Serial | Interface | <input type="checkbox"/> V.35 <input type="checkbox"/> X.21 |
| | Data Rate | |
| | Clock | <input type="checkbox"/> Normal <input type="checkbox"/> Inverse |
| | RTS | <input type="checkbox"/> On <input type="checkbox"/> From DTE |
| | CTS | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From RTS |
| | DSR | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DTR |
| | DCD | <input type="checkbox"/> On <input type="checkbox"/> Off <input type="checkbox"/> From DSL |
| | Delay | <input type="checkbox"/> 0mS <input type="checkbox"/> 1mS <input type="checkbox"/> 2mS <input type="checkbox"/> 3mS |

3.8.8 Multi-interface model--E1+Ethernet Interface

| | | |
|----------|----------------|--|
| NTU | Interface | <input type="checkbox"/> E1 <input type="checkbox"/> Serial <input type="checkbox"/> Ethernet <input type="checkbox"/> E1+Serial <input checked="" type="checkbox"/> E1+Ethernet |
| | Type | <input type="checkbox"/> STU-R <input type="checkbox"/> STU-C-INTCLK <input type="checkbox"/> STU-C-EXTCLK |
| SHDSL | Annex | <input type="checkbox"/> A <input type="checkbox"/> B |
| | PSD | <input type="checkbox"/> R1_ASTM <input type="checkbox"/> R2_ASYM <input type="checkbox"/> SYM_ENABLE <input type="checkbox"/> ASYM_DISABLE |
| | SNR Margin | <input type="checkbox"/> DISABLE <input type="checkbox"/> 0 <input type="checkbox"/> 1 <input type="checkbox"/> 2 <input type="checkbox"/> 3 <input type="checkbox"/> 4 <input type="checkbox"/> 5 <input type="checkbox"/> 6 <input type="checkbox"/> 7 <input type="checkbox"/> 8 <input type="checkbox"/> 9 <input type="checkbox"/> 10 |
| | Power Back Off | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| E1 | Channel | <input type="checkbox"/> PCM31 <input type="checkbox"/> PCM31C <input type="checkbox"/> PCM30 <input type="checkbox"/> PCM30C <input type="checkbox"/> Unframed |
| | Slot Number | |
| | First Slot | |
| | Code | <input type="checkbox"/> HDB3 <input type="checkbox"/> AMI |
| | AIS | <input type="checkbox"/> Off <input type="checkbox"/> On |
| | Build Outs | <input type="checkbox"/> 75 Ohm <input type="checkbox"/> 120 Ohm |
| Ethernet | Date Rate | |
| | Auto Config | <input type="checkbox"/> Disable <input type="checkbox"/> Enable |
| | Speed | <input type="checkbox"/> Full <input type="checkbox"/> Half |
| | Duplex | <input type="checkbox"/> 100M <input type="checkbox"/> 10M |

4 Configuration with Console Port

This chapter will deal with the specifics of configuration and operation of this product via console port with terminal emulation program. The configuration UM-SN VER.2 NTU is performed via a menu-driven embedded software, using a standard ASCII terminal or a PC running a terminal emulation application connected to the rear panel CONSOLE port.

Windows includes a terminal emulation program called HyperTerminal. Connect the appropriate communication port from the PC to this device. After the physical connection is made, you are ready to configure this product. Make sure you have connected the supplied RS-232C serial cable (DB9F to RJ-45 Plug) to the console port on the rear panel on this product.

Run the terminal emulation program such as Hyper Terminal with the following setting:

Emulation: VT-100 compatible

Band rate: 115200, Data bits: 8, Parity: None, Stop Bits:1 , Flow Control: None

4.1 Login Procedure

At the start up screen, you will see:

```
DownLoad FPGA Code 000111ad/000111ad...0k
SHDSL (Ethernet) Interface, STU_C_INTCLK Mode
Model = 5030G V2 Software Version = 1.03.20 FPGA Version = 1.02
MCSV 1536-0000-10193BB4 / 1536-0000-103C38F9
```

Press SPACE key to enter console mode configuration!

Press the SPACE key until the login screen appears. When you see the login screen, you can logon to device. Username use “**admin**”. When the system prompts you for a password, type “**admin**” to enter is O.K.

```
User: admin
Password: *****_
```

4.2 Window structure

After you type the password, it will display the main menu.

```
SHDSL NTU
-----
>> setup      Configure system
   status     Show running system status
   show       View system configuration
   reboot     Reset and boot system
   diag       Diagnostic utility
   upgrade    Console software upgrade
   exit       Quit system

-----

Command:setup <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Above screen capture shows the common structure for all windows used throughout the configuration console terminal.

From top to bottom, the window is divided into four major sections.

The very top line displays the product name.


Next a block of commands is listed where the ">>" symbol indicates the current cursor placeholder.

The next block down is the "command" section. The command that is selected and ready for execution is displayed after the "Command:" prompt. The "<more...>" designation indicates that there are other sub menus to this command. The "Message:" field is used to display any special system messages or warnings.

Finally, at the very bottom of the screen is a help command line and reminder of the currently available command keys. In most cases, the keyboards four cursor keys can be used to navigate all the menu system. If for some reason your keyboard's cursor keys are not supported in the terminal emulation software, you may uses the keys listed on the help command line.

4.3 Menu Commands

Before changing the configuration, familiarize yourself with the operations list in the following table. The operation list will be shown on the window.



| Keypads | Description |
|-------------------------------|---|
| [UP] or I | Move to above field in the same level menu |
| [DOWN] or K | Move to below field in the same lever menu |
| U | Move to top field in the same level menu |
| O | Move to bottom field in the same level menu |
| [LEFT] or J | Move back to previous menu (Exit) |
| [RIGHT] , L or [ENTER] | Move forward to submenu(Enter) |
| [TAB] | To choose another parameters |
| Ctrl + C | To quit the show data display screen |

4.4 Main Menu Summary

The main menu is prompt as follow.

| Menu Title | Function |
|------------|--|
| Setup | To setup SHDSL type, SHDSL parameters and E1/Serial/Ethernet parameters or restore factory default setting. |
| Status | To show SHDSL status, E1 /V.35/Ethernet status and statistics or clear the statistics on both local and remote side. |
| Show | To show general information, all configurations and all configurations in command script format. |
| Reboot | To reboot the system |
| Diag | To setup diagnostic utility |
| Upgrade | To upgrade firmware (kernel and FPGA code) |
| Exit | To exit this system |

4.5 [Setup] Configuration

This section provides information about configuration the UM-SN VER.2 NTU. Follow the procedures:

In main menu, select **setup** and press [ENTER] or [RIGHT]

```
SHDSL NTU
-----
>> setup          Configure system
   status         Show running system status
   show           View system configuration
   reboot         Reset and boot system
   diag           Diagnostic utility
   upgrade        Console software upgrade
   exit           Quit system

-----

Command:setup <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Press [ENTER] or [L] key to select which channel (Local side or Remote side).

```
SHDSL NTU
-----
>> LocCh          Setup Local Channel
   RmtCh          Setup Remote Channel

-----

Command:LocCh <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The screen will prompt as following:

E1 interface model

```

                                SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHSDL Parameters
   E1             Configure E1 Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see E1 parameter can be setting.

Serial interface model

```

                                SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHSDL Parameters
   Serial         Configure Serial Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see Serial parameter can be setting.

Ethernet interface model

```
SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHDSL Parameters
   Ethernet       Configure Ethernet Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see Ethernet parameter can be setting.

E1 and Serial interface model

```
SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHDSL Parameters
   E1             Configure E1 Parameters
   Serial         Configure Serial Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see the E1 and Serial parameters can be setting.

E1 and Ethernet interface model

| SHDSL NTU | |
|--------------|-------------------------------|
| >> Interface | Configure NTU Interface |
| Shdsl | Configure SHSDL Parameters |
| E1 | Configure E1 Parameters |
| Ethernet | Configure Ethernet Parameters |
| Rmtcfg | Enable/Disable Remote Config |
| Default | Restore NTU's Default Setting |

Command:Interface <CR> _
Message:

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

You can see the E1 and Ethernet parameters can be setting.

4.5.1 Configure Interface

Select **Interface** item, and press [ENTER] or [RIGHT] to setup NTU Interface.

```
SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHSDL Parameters
   E1             Configure E1 Parameters
   Ethernet       Configure Ethernet Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

```
SHDSL NTU
-----
>> Interface      Configure NTU Interface
   Shdsl          Configure SHSDL Parameters
   E1             Configure E1 Parameters
   Ethernet       Configure Ethernet Parameters
   Rmtcfg         Enable/Disable Remote Config
   Default        Restore NTU's Default Setting

-----

Command:Interface <CR>
Message: Please input the following information.

SHDSL Interface (TAB Select) <E1+Ethernet>: E1+Ethernet

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Press [TAB] to select the operating type and press enter to finish setting.

| Model | Interface modes support |
|--------------------------|-------------------------|
| E1 interface model | E1 |
| Serial interface model | Serial |
| Ethernet interface model | Ethernet |
| Multi-interfaces model | E1 |
| | Serial |
| | Ethernet |
| | E1+Serial |
| | E1+Ethernet |

For Multi-interfaces model, there have five types for your selection: **E1**, **Serial**, **Ethernet**, **E1+ Serial** and **E1+ Ethernet**.

4.5.2 Configure SHDSL parameters

This section will introduce the configuring of SHDSL parameters.

Select **Shdsl** , and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
Interface      Configure NTU Interface
>> Shdsl       Configure SHDSL Parameters
E1             Configure E1 Parameters
Ethernet       Configure Ethernet Parameters
Rmtcfg        Enable/Disable Remote Config
Default       Restore NTU's Default Setting

-----

Command:Shdsl <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The SHDSL parameters items have **SHDSL Mode**, **Annex type**, **PSD**, **SNR margin** and **Power backoff**.

```
SHDSL NTU
-----
>> Mode        Configure SHDSL Mode
Annex          Configure SHDSL Annex
Psd            Configure SHDSL PSD Mask
Margin         Configure SHDSL SNR Margin
Pwr Backoff    Configure SHDSL Power backoff

-----

Command:Mode <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

For configuring SHDSL mode, move the cursor to **Mode** and press [ENTER] or [L]. Select the SHDSL mode by using [TAB] key.

Setup SHDSL parameter, Mode

```

                                SHDSL NTU
-----
>> Mode           Configure SHDSL Mode
   Annex          Configure SHDSL Annex
   Psd            Configure SHDSL PSD Mask
   Margin         Configure SHDSL SNR Margin
   Pwr Backoff    Configure SHDSL Power backoff

-----

Command:Mode <CR>
Message: Please input the following information.

SHDSL Mode (TAB Select) <STU-R>: STU-R

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

There are three SHDSL modes can be used: **STU-R**, **STU-C-INTCLK** and **STU-C-EXTCLK**.

INTCLK: The device will generate the appropriate clock speed defined by the speed setting of the interface.

EXTCLK: The device will accept the clock from the interface and will use that clock to receive and transmit data across the interface.

Most applications use Internal Clock. If the DTE provides a clock with TX data, the clock can set to be External Clock.

For configuring SHDSL Annex type, move the cursor to **Annex** and press [ENTER or [L]]. Select the Annex type by using [TAB] key.

Setup SHDSL parameter, Annex

```
SHDSL NTU
-----
Mode          Configure SHDSL Mode
>> Annex      Configure SHDSL Annex
Psd           Configure SHDSL PSD Mask
Margin        Configure SHDSL SNR Margin
Pwr Backoff   Configure SHDSL Power backoff

-----
Command:Annex <CR>
Message: Please input the following information.

SHDSL Annex (TAB Select) <Annex-B>: Annex-B

-----
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

There are two annex type can be used: **Annex-A** and **Annex-B**

For configuring SHDSL PSD, move the cursor to **psd** and press [ENTER] or [L]. Select the parameter by using [TAB] key.

Setup SHDSL parameter, PSD

```

                                SHDSL NTU
-----
Mode          Configure SHDSL Mode
Annex         Configure SHDSL Annex
>> Psd        Configure SHDSL PSD Mask
Margin        Configure SHDSL SNR Margin
Pwr Backoff   Configure SHDSL Power backoff

-----

Command:Psd <CR>
Message: Please input the following information.

SHDSL PSD Mask (TAB Select) <R1_ASM>: R1_ASM_

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

There are four PSD type can be used: **R1_ASM**, **R2_ASM**, **SYM_ENABLE** and **ASYM_DISABLE**.

For setting SHDSL Margin, move the cursor to **margin** and press [ENTER] or [L]. You can key the SHDSL margin setting value.

Setup SHDSL parameter, SNR Margin

```

                                SHDSL NTU
-----
Mode          Configure SHDSL Mode
Annex         Configure SHDSL Annex
Psd           Configure SHDSL PSD Mask
>> Margin     Configure SHDSL SNR Margin
Pwr Backoff   Configure SHDSL Power backoff

-----

Command:Margin <CR>
Message: Please input the following information.

SHDSL Startup Margin (TAB Select) <0~10> (0) : 0~10
SHDSL Current Margin <0> (0~10): _

-----
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

SNR margin is an index of line connection. You can see the actual SNR margin from 0 to 10 in STATUS SHDSL. The larger SNR margin has the better line connection. For example, if you set SNR margin in the field as 3, the SHDSL connection will drop down and reconnect when the SNR margin is lower than 3.

For configuring SHDSL Power Back off function, move the cursor to **Pwr Backoff** and press [ENTER] or [L]. Select the parameter by using [TAB] key.

Setup SHDSL parameter, Power Backoff

```
SHDSL NTU
-----
Mode          Configure SHDSL Mode
Annex         Configure SHDSL Annex
Psd           Configure SHDSL PSD Mask
Margin        Configure SHDSL SNR Margin
>> Pwr Backoff Configure SHDSL Power backoff

-----
Command:Pwr Backoff <CR>
Message: Please input the following information.

SHDSL Power BackOff (TAB Select) <Disable>: Disable_

-----
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

There are two power back-off type can be used: **Disable** and **Enable**.

4.5.3 Configure E1 parameters

When using on E1 interface, select the E1 item and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHDSL Parameters
>> E1          Configure E1 Parameters
Rmtcfg         Enable/Disable Remote Config
Default        Restore NTU's Default Setting

-----

Command:E1 <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The E1 settings include Channel, line code, AIS and build out settings.

Setup E1 Parameter, Channel

```
SHDSL NTU
-----
>> Channel      Configure E1 Channel
Code           Configure E1 code
Ais            Configure E1 AIS
Build_outs     Configure E1 build outs

-----

Command:Channel <CR>
Message:

-----


<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Framing is required to recover the channelized E1. In transparent operation, the framing is configured as Unframed. In this case the UM-SN VER.2 framer must be set to Nx64 with N=32. For any framing such as FAS or CAS, the UM-SN VER.2 framer must be set to E1, then the E1 framing here may be set accordingly. The default setting is PCM31C.

| Channel | Framing |
|---------|------------------------------|
| PCM31 | FAS |
| PCM31C | FAS+CRC4 |
| PCM30 | FAS+CAS |
| PCM30C | FAS+CAS+CRC4 |
| FULL | Unframed E1 (transparent) |


| | |
|------------|--|
| FAS | Frame Alignment Signal use 7-bit pattern to establish and maintain frame synchronization. The FAS word is located in timeslot 0 of frame. In FAS mode there have 1~31 timeslot available for use data. |
|------------|--|

PCM31 and PCM31C / FAS and FAS+CRC4




| | |
|------------|---|
| CAS | Also known as time slot 16 multiframing. It requires a multiframe alignment signal to be present for frame sync. The Multiframe Alignment Signal (MFAS) is inserted into the 16th timeslot of frame 0 of the 16-frame multiframe. In CAS mode, there have 30 channels available for user data. If timeslot 16 is included in the unit's mapping, it will be disregarded. |
|------------|---|

PCM30 and PCM30C / FAS+CAS and FAS+CAS+CRC4




| | |
|-----------------|--|
| CRC4 | <p>The CRC-4 checksum bits are transmitted in the outgoing E1 data stream.</p> <p>Also the received signal is checked for errors.</p> <p>CRC-4 checksum cannot be sent in unframed mode.</p> |
| Unframed | <p>In this mode, user data is inserted into all 32 channels (64k x 32 = 2048k) of the E1 stream. The object of running without framing is to utilize the full bandwidth of the E1 line.</p> |


UNFRAMED



G.703 (E1) can supports data rate of 2048kbps, so the maximum data rate of SHDSL line, connected with E1 DCEs, depends on data rate of E1, 2048kbps.



If the connection is E1 vs V.35 or V.35 vs E1, the frame has to be used N x 64k. In this case, the data rate depends on value of N. Same as above case, SHDSL and V35 can support 2304kbps data rate (36 x 64k) but E1 supports maximum data rate of 2048kbps (32 x 64k).




Time slot, N value, is place of data in the frame. Time Slot Number 1~31 (N=1~31) is Fractional E1 and Time Slot Number 32 (N=32) is unframed.

Fractional E1

For fractional E1 (FE1), the data rate is from 64k, N=1, to 1984k, N=31, according to the E1 frame. If the E1 frame is PCM31(FAS) or PCM31C(FAS+CRC4), there have 1~31 available time slot for used data.

For example, if the data rate of SHDSL line set to be 512k, the time slot number is 8 and first time slot number is 1. The frame is shown as below.




The First Time Slot setting of FAS and FAS+ CRC4 (PCM31 and PCM31C)have to follow the rule:

RULE

First Time Slot ≤ 31- Time Slot Number

Using E1 frame of FAS+CAS or FAS+CAS+CRC4(PCM30 or PCM30C), the [FAS] will occupy Time Slot 0 and [CAS] will occupy Time Slot 16. There have only 30 Time Slot left for data. On the other hand, the data rate is 1920kbps (30x64Kbps).




The First Time Slot setting of FAS+CAS and FAS+CAS+CRC4 (PCM30 and PCM30C) have to follow the rule:

RULE

First Time Slot ≤ 30 - Time Slot Number

Unframed E1

Used data is inserted into all 32 channels (64Kbps x 32 = 2048Kpbs) of the E1 stream



Setup E1 Parameter, Line Code

| SHDSL NTU | |
|---|-------------------------|
| Channel | Configure E1 Channel |
| >> Code | Configure E1 code |
| Ais | Configure E1 AIS |
| Build_outs | Configure E1 build outs |
| <hr/> Command:Code <CR> _ Message: | |
| <hr/> <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | |

The UM-SN VER.2 NTU supports two different line codes: HDB3 and AMI.

HDB3 is the most popular and preferred line coding and is also the default setting.

AMI line coding is also selectable.

| | |
|------|---|
| HDB3 | In this line coding, the transmitter substitutes a deliberate bipolar violation when excessive zeros in the data stream are detected. The receiver recognizes these special violations and decodes them as zeros. This method enables the network to minimum pulse density requirements. Unless AMI is required for your application, HDB3 should be used whenever possible. |
| AMI | Alternate Mark Inversion defines a pulses as a "mark," a binary one as, as opposed to a zero. In an E1 network connection, signals are transmitted as a sequence of one and zero. One is sent as pulse, and zero is sent as spaces, i.e. no pulse. Every other pulse is inverted from the previous pulse in polarity, so that the signal can be effectively transmitted. This means, however, that a long sequence of zero in data stream will cause problems, since the NTU receiving the signal relies on the signal to recover the 2048kbps clock. |


| SHDSL NTU | | | |
|------------|--------------|------------|--|
| Channel | Configure E1 | Channel | |
| Code | Configure E1 | code | |
| >> Ais | Configure E1 | AIS | |
| Build_outs | Configure E1 | build outs | |

Command:Ais <CR>
Message:


<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

AIS (Alarm Indication Signal) is a method to inform the remote connection that there is a signal or sync problem with the E1. AIS is only valid in framed mode E1, not in Unframed E1. The setting here of AIS enabled (on) or not (off) and is for testing with AIS. When enabled, the E1 will transmit the AIS and it should be confirmed at the remote device (AIS indication lit). After testing, please turn AIS back off.

For example 1: When STU-R E1 RX line is drop, STU-R sends the status to STU-C via EOC or command, and then STU-C will send AIS (Alarm Indication Signal) to DTE while AIS function is enabled.



For example 2: When SHDSL connection drops, STU-R and STU-C both send AIS (Alarm Indication Signal) to DTE in the same time while AIS function is enabled.



Setup E1 Parameter, Build Out

| SHDSL NTU | |
|---------------|-------------------------|
| Channel | Configure E1 Channel |
| Code | Configure E1 code |
| Ais | Configure E1 AIS |
| >> Build_outs | Configure E1 build outs |

| | |
|-------------------------|--|
| Command:Build_outs <CR> | |
| Message: | |

| | |
|---|--|
| <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | |
|---|--|

The UM-SN VER.2 NTU can support both unbalanced E1 at 75 ohms and balanced E1 at 120 ohms. The settings for impedance are made here under the build out menu setting.

4.5.4 Configure Serial parameters

When using on Serial interface, select the Serial item and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHDSL Parameters
>> Serial      Configure Serial Parameters
Rmtcfg         Enable/Disable Remote Config
Default        Restore NTU's Default Setting

-----

Command:Serial <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The serial settings include the Interface, data rate, clocking and handshaking lines (RTS, CTS, DSR and DCD) setup etc.

```
SHDSL NTU
-----
>> Interface    Configure Serial Interface
Data rate      Configure Serial Data Rate (N*64)
Clock          Configure Serial clock
Rts            Configure Serial rts
Cts            Configure Serial cts
Dsr            Configure Serial dsr
Dcd            Configure Serial dcd
Delay          Configure Serial delay

-----

Command:Interface <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```


Setup Serial Parameter, Interface

```
SHDSL NTU
-----
>> Interface          Configure Serial Interface
   Data rate          Configure Serial Data Rate (N*64)
   Clock              Configure Serial clock
   Rts                Configure Serial rts
   Cts                Configure Serial cts
   Dsr                Configure Serial dsr
   Dcd                Configure Serial dcd
   Delay              Configure Serial delay

-----

Command:Interface <CR>
Message: Please input the following information.

Change V.35 Interface (TAB Select) <V35>: V35

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can set serial interface as V.35 or RS-530(X.21) hardware standard.

Setup Serial Parameter, Data Rate

```
SHDSL NTU
-----
>> Interface          Configure Serial Interface
   Data rate          Configure Serial Data Rate (N*64)
   Clock              Configure Serial clock
   Rts                Configure Serial rts
   Cts                Configure Serial cts
   Dsr                Configure Serial dsr
   Dcd                Configure Serial dcd
   Delay              Configure Serial delay

-----

Command:Data rate <CR>
Message: Please input the following information.

Change Serial Nx64 (TAB Select) <32>: 32_

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

For serial data rate, the default setting is N=32. The data rate can be adjusted in increments of 64kbps from 64kbps to 2304kbps (N=1~36).

Setup Serial Parameter, Clock Polarity

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| >> Clock | Configure | Serial | clock |
| Rts | Configure | Serial | rts |
| Cts | Configure | Serial | cts |
| Dsr | Configure | Serial | dsr |
| Dcd | Configure | Serial | dcd |
| Delay | Configure | Serial | delay |

Command:Clock <CR>
Message: Please input the following information.

Change Serial Clock (TAB Select) <normal>: normal_

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The data port clock polarity may be adjusted to solve some rare clocking issues. The default setting is 'Normal' clock polarity, where data is sent on the positive transition of the clock, while the option exists to set inverse clock polarity where data is sent on the negative clock transition.

Setup Serial Parameter, RTS

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| Clock | Configure | Serial | clock |
| >> Rts | Configure | Serial | rts |
| Cts | Configure | Serial | cts |
| Dsr | Configure | Serial | dsr |
| Dcd | Configure | Serial | dcd |
| Delay | Configure | Serial | delay |

Command:Rts <CR>
Message: Please input the following information.

Change Serial RTS (TAB Select) <on>: on_

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The behavior of the RTS (Request To Send) signal may be set in one of two ways. When set 'on', the RTS signal is always forced high (on, positive voltage or SPACE), when set 'from DTE' the RTS signal will follow the DTE's condition. The default setting for RTS is ON.

Setup Serial Parameter, CTS

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| Clock | Configure | Serial | clock |
| Rts | Configure | Serial | rts |
| >> Cts | Configure | Serial | cts |
| Dsr | Configure | Serial | dsr |
| Dcd | Configure | Serial | dcd |
| Delay | Configure | Serial | delay |

Command:Cts <CR>
Message: Please input the following information.
Change Serial CTS (TAB Select) <from_rts>: from_rts_

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The behavior of the CTS (Clear To Send) signal may be set in one of three ways. When set 'on', the CTS signal is always forced high (on, positive voltage or SPACE), when set 'off' the signal is always forced low (off, negative voltage or MARK), or CTS will follow RTS (Request To Send) condition of 'on' for RTS on 'off' for RTS off. The default setting for CTS is to follow RTS.

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| Clock | Configure | Serial | clock |
| Rts | Configure | Serial | rts |
| Cts | Configure | Serial | cts |
| >> Dsr | Configure | Serial | dsr |
| Dcd | Configure | Serial | dcd |
| Delay | Configure | Serial | delay |

Command:Dsr <CR>
 Message: Please input the following information.

Change Serial DSR (TAB Select) <on>: on

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The behavior of the DSR (Data Set Ready) signal may be set in one of three ways. When set 'on', the DSR signal is always forced high (on, positive voltage or SPACE), when set 'off' the signal is always forced low (off, negative voltage or MARK), or DSR will follow DTR (Data Terminal Ready) condition of 'on' for DTR on or 'off' for DTR off. The default setting for DSR is ON.

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| Clock | Configure | Serial | clock |
| Rts | Configure | Serial | rts |
| Cts | Configure | Serial | cts |
| Dsr | Configure | Serial | dsr |
| >> Dcd | Configure | Serial | dcd |
| Delay | Configure | Serial | delay |

Command:Dcd <CR>
 Message: Please input the following information.

Change Serial DCD (TAB Select) <from_dsl>: from_dsl

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The behavior of the DCD (Data Carrier Detect) signal may be set in one of three ways. When set 'on', the DCD signal is always forced high (on, positive voltage or SPACE), when set 'off' the signal is always forced low (off, negative voltage or MARK), or DCD will follow the DSL condition of 'on' for DSL link or 'off' for DSL no link. The default setting for DCD is to follow the DSL link status.

Setup Serial Parameter, Delay

| SHDSL NTU | | | |
|-----------|-----------|--------|------------------|
| Interface | Configure | Serial | Interface |
| Data rate | Configure | Serial | Data Rate (N*64) |
| Clock | Configure | Serial | clock |
| Rts | Configure | Serial | rts |
| Cts | Configure | Serial | cts |
| Dsr | Configure | Serial | dsr |
| Dcd | Configure | Serial | dcd |
| >> Delay | Configure | Serial | delay |

Command: Delay <CR>
Message: Please input the following information.

Change Serial Delay <3> (0~3): 3

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

The delay setting is used to cause a delay for CTS to follow RTS. The delay setting may be set from 0 to 3 milliseconds. The default setting is 3 milliseconds.

4.5.5 Configure Ethernet parameters

When using on Ethernet interface mode, select the Ethernet item and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHDSL Parameters
>> Ethernet    Configure Ethernet Parameters
Rmtcfg         Enable/Disable Remote Config
Default        Restore NTU's Default Setting

-----

Command:Ethernet <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The Ethernet settings include the data rate, auto config, duplex and speed.

```
SHDSL NTU
-----
>> Rate        Configure Ethernet Data Rate(N*64K)
Auto           Configure Ethernet Auto Config
Duplex         Configure Ethernet Duplex
Speed          Configure Ethernet Speed

-----

Command:Rate <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```


Setup Interface Parameter, Data Rate

```

                                SHDSL NTU
-----
>> Rate          Configure Ethernet Data Rate(N*64K)
   Auto          Configure Ethernet Auto Config
   Duplex        Configure Ethernet Duplex
   Speed         Configure Ethernet Speed

-----

Command:Rate <CR>
Message: Please input the following information.

Change Ethernet Rate <36> (3~36): _

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

For data rate, the default setting is 36, or full rate. The data rate can be adjusted in increments of 64kbps from 64kbps to 2304kbps (N=1~36).

Setup Ethernet Parameter, Auto Configuration

```

                                SHDSL NTU
-----
>> Rate          Configure Ethernet Data Rate(N*64K)
   Auto          Configure Ethernet Auto Config
   Duplex        Configure Ethernet Duplex
   Speed         Configure Ethernet Speed

-----

Command:Auto <CR>
Message: Please input the following information.

Change Ethernet Auto Config (TAB Select) <Enable>: Enable_

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

You can select Enable and Disable on auto configuration.

When auto configuration set enable, the other parameter Duplex and Speed can't need to setup.

On this case, the message will show as "Ethernet is in auto negotiate"

```

                                SHDSL NTU
-----
Rate          Configure Ethernet Data Rate(N*64K)
Auto          Configure Ethernet Auto Config
>> Duplex     Configure Ethernet Duplex
Speed         Configure Ethernet Speed

-----

Command: Duplex <CR> Ethernet is in auto negotiate
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

```

                                SHDSL NTU
-----
Rate          Configure Ethernet Data Rate(N*64K)
Auto          Configure Ethernet Auto Config
Duplex        Configure Ethernet Duplex
>> Speed      Configure Ethernet Speed

-----

Command: Speed <CR> Ethernet is in auto negotiate
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

If auto configuration set disable, the other parameter Duplex and Speed can setup.

Setup Ethernet Parameter, Duplex

```
SHDSL NTU
-----
Rate          Configure Ethernet Data Rate(N*64K)
Auto          Configure Ethernet Auto Config
>> Duplex     Configure Ethernet Duplex
Speed         Configure Ethernet Speed

-----

Command: Duplex <CR>
Message: Please input the following information.

Change Ethernet Duplex (TAB Select) <Full-Duplex>: Full-Duplex_

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can set up the duplex mode is Full-Duplex and Half-Duplex.

Setup Ethernet Parameter, Speed

```
SHDSL NTU
-----
Rate          Configure Ethernet Data Rate(N*64K)
Auto          Configure Ethernet Auto Config
Duplex        Configure Ethernet Duplex
>> Speed      Configure Ethernet Speed

-----

Command: Speed <CR>
Message: Please input the following information.

Change Ethernet Speed (TAB Select) <100M>: 100M

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can set up the Ethernet speed is 10Mbps or 100Mbps.

4.5.6 Enable and Disable Remote configuration

You can set the "Enable/Disable Remote Config Capability" to let the remote side can configure parameters to this device remotely.

```
-----
                                SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHSDL Parameters
Ethernet       Configure Ethernet Parameters
>> Rmtcfg      Enable/Disable Remote Config
Default        Restore NTU's Default Setting

-----

Command:Rmtcfg <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.5.7 Restore factory default setting

The UM-SN VER.2 NTU can have all settings restored to their original factory settings simply by going to the setting menu, selecting the Default item, and then press ENTER. The system will ask for a y(es) or n(o) confirmation followed by an ENTER.

```
SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHDSL Parameters
Ethernet       Configure Ethernet Parameters
Rmtcfg         Enable/Disable Remote Config
>> Default     Restore NTU's Default Setting

-----

Command:Default <CR>
Message: Please input the following information.

Are you sure? (y/n):

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

When display DONE, it means that is restore suceesfully.

```
SHDSL NTU
-----
Interface      Configure NTU Interface
Shdsl          Configure SHDSL Parameters
Ethernet       Configure Ethernet Parameters
Rmtcfg         Enable/Disable Remote Config
>> Default     Restore NTU's Default Setting

-----

Command:Default <CR>
Message: Done_

Are you sure? (y/n): y

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The default vaules are as the following:

| | | |
|----------|--|--|
| SHDSL | setup NTU Interface setup NTU Type setup Shdsl Annex setup Shdsl Psd setup Shdsl Margin setup Shdsl Power BackOff | E1 STU-R Annex-B ASYM_DISABLE 0 Disable |
| E1 | setup E1 Channel setup E1 Slot Number setup E1 First Slot setup E1 code setup E1 AIS setup E1 Build Outs | PCM31C 31 1 HDB3 Off 120 Ohm |
| Serial | setup Serial Interface setup Serial Data Rate setup Serial Clock setup Serial Rts setup Serial Cts setup Serial Dsr setup Serial Dcd setup Serial Delay | V35 32 normal on from_rts on from_dsl 3 |
| Ethernet | Setup Ethernet Rate setup Ethernet Auto Config setup Ethernet Speed setup Ethernet Duplex | 36 Enable Auto negotiate Auto negotiate |

4.6 [Status] View the system status

You can use the status command to view the status of SHDSL, E1, Serial and Interface as well as statistic and clear the statistic log. Select **status** and press [ENTER].

If the two sets of SHDSL NTU connection is ready, you can also view the remote side's statistic data.

```
SHDSL NTU
-----
  setup          Configure system
>> status       Show running system status
  show           View system configuration
  reboot         Reset and boot system
  diag           Diagnostic utility
  upgrade        Console software upgrade
  exit           Quit system

-----

Command:status <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.6.1 Show SHDSL Status

Select **SHDSL** command to show the status of SHDSL.

```
SHDSL NTU
-----
>> Shdsl          Show SHDSL Status
   Interface      Show Interface Status
   Current Perf   Show Current Performance
   Loc_statistics Show Local Statistics
   Rmt_statistics Show Remote Statistics
   clear          Clear Channel Statistics

-----

Command:Shdsl <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see the following screen:

```
SHDSL NTU
-----
<Shdsl Status>
Channel          :          LocA          RmtA
STU Type         : STU-C-INTCLK
DSL Type         : SHDSL
Line Rate(Kbps)  : 0
SNR Margin (dB)  : 0.0
Attenuation(dB)  : 0.0
Receiver Gain(dB): 0.0
Transmit Power(dBm) : 0.0

Loopback State   : Disable
Bert Test State  : Disable
Bert Sync        : Not Sync
Bert Error Count : 0
Refresh counter:10, Press 'Ctrl+C' to quit...

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The SHDSL status will display a real-time status of the SHDSL on local side and remote side if the two NTUs have connected. The screen is refreshed about every 1.5 seconds. The monitoring window displays the SHDSL line parameters, such as Line Rate, SNR margin, attenuation and Receiver Gain, Transmit Power, Loopback and BERT status etc. The below side of window displays the loopback and BER test status.

Table of SHDSL Line rate vs. Data rate:

| SHDSL Line rate | Data Rate (kbps) | |
|-----------------|----------------------------|-------------------------------|
| | Number of time slot for E1 | Nx64K for Serial and Ethernet |
| 2304(n=36) | Can't use | 36 |
| 2240(n=35) | Can't use | 35 |
| 2176(n=34) | Can't use | 34 |
| 2112(n=33) | Can't use | 33 |
| 2048(n=32) | 32(unframed) | 32 |
| 1984(n=31) | 31 | 31 |
| 1920(n=30) | 30 | 30 |
| 1856(n=29) | 29 | 29 |
| 1792(n=28) | 28 | 28 |
| | | ... |
| | | ... |
| | | ... |
| | | ... |
| 384(n=6) | 6 | 6 |
| 320(n=5) | 5 | 5 |
| 256(n=4) | 4 | 4 |
| 192(n=3) | 3 | 3 |
| 192(n=3)* | 2 | 2 |
| 192(n=3)* | 1 | 1 |

Note (*) : Due to SHDSL working line rate is start up from 192kbps(n=3) , all setting on all interface with apply 64kbps(n=1) and 128kbps(n=2) are actually using on 192kbps DSL line rate.

4.6.2 Show Interface Status

Select the Interface command to show the Interface status:

```
SHDSL NTU
-----
Shdsl          Show SHDSL Status
>> Interface    Show Interface Status
Current Perf    Show Current Performance
Loc_statistics  Show Local Statistics
Rmt_statistics  Show Remote Statistics
clear           Clear Channel Statistics

-----

Command:Interface <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

You can see all the interface status of E1, V.35 and Ethernet according which interface are you used. While in this display mode the terminal window will not timeout. To exit the window, press CTRL-C.

```
SHDSL NTU
-----
Channel          :          LocA          RmtA
STU Type         :          STU-R          STU-C-INTCLK
Interface        :          E1             E1
E1 DataRate(Kpbs) :          1984          1984
E1 Sync          :          Down           Down
E1 AIS Alarm     :          On             Off

V35 DataRate(Kpbs) :
V35 DCD          :
V35 DSR          :
V35 CTS          :
V35 RTS          :
V35 DRT          :

Eth DataRate(Kpbs) :
Eth Link         :
Eth Speed        :
Eth Duplex       :

Refresh counter:10, Press 'Ctrl+C' to quit...

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.6.3 Show Current Performance

Select Current Perf command to show the Current Performance.

```
SHDSL NTU
-----
Shdsl          Show SHDSL Status
Interface      Show Interface Status
>> Current Perf Show Current Performance
Loc_statistics Show Local Statistics
Rmt_statistics Show Remote Statistics
clear          Clear Channel Statistics

-----

Command:Current Perf <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

This window displays the accumulated performance data for the current 15 minute interval and for the current 24 hour interval. While in this display mode the terminal window will not timeout. To exit the window, press CTRL-C.

SHDSL NTU

Shdsl Performance

| | | | |
|----------------|-------|------|-----------|
| Channel | : | LocA | RmtA |
| Interface | : | E1 | E1 Serial |
| Current 15Min | ES | 0 | 0 |
| | SES | 0 | 0 |
| | UAS | 0 | 0 |
| | LOSWS | 0 | 0 |
| Current 24Hour | ES | 0 | 0 |
| | SES | 0 | 0 |
| | UAS | 114 | 6041 |
| | LOSWS | 0 | 0 |

E1 Performance

| | | | |
|----------------|-----|------|-------|
| Current 15Min | ES | 0 | 0 |
| | SES | 0 | 0 |
| | UAS | 647 | 650 |
| Current 24Hour | ES | 0 | 0 |
| | SES | 0 | 0 |
| | UAS | 1493 | 14808 |

Refresh counter:1, Press 'Ctrl+C' to quit...

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

4.6.4 View the Local and remote Statistics

Select **Loc_statistic** command to show the local side statistic information.

```
SHDSL NTU
-----
Shdsl          Show SHDSL Status
Interface      Show Interface Status
Current Perf   Show Current Performance
>> Loc_statistics Show Local Statistics
Rmt_statistics Show Remote Statistics
clear          Clear Channel Statistics

-----

Command:Loc_statistics <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

It also have 15 minutes or 24 hour via [TAB] to choose

```
SHDSL NTU
-----
Shdsl          Show SHDSL Status
Interface      Show Interface Status
Current Perf   Show Current Performance
>> Loc_statistics Show Local Statistics
Rmt_statistics Show Remote Statistics
clear          Clear Channel Statistics

-----

Command:Loc_statistics <CR>
Message: Please input the following information.

Shdsl Channel Statistics (TAB Select) <15m>: 15m

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The statistics display window will display performance monitor data for the selected interval (15 minutes or 24 hours).

The display will show the recorded results for ES (error seconds), SES(severely errored seconds), UAS (unavailable seconds), and LOSW (loss of sync word). While in this display mode the terminal window will not timeout. The 15 minute display window will display all the performance information for each 15 minute interval in the current 24 hour period. There are a total of 96 intervals.

Press the ENTER key to display the next page of intervals. To exit the window, press CTRL-C and then ENTER.

The performance monitor is capable of storing and retrieving performance information for each 24 hour interval, up to 7 days.

For **E1 Interface mode** , there have SHDSL and E1 item.

View the performance monitor data for the selected interval 15 minutes:

| SHDSL NTU | | | | | | | |
|---|-------|-----|-----|------|----|-----|-----|
| ----- | | | | | | | |
| Local | SHDSL | | | | E1 | | |
| | ES | SES | UAS | LOSW | ES | SES | UAS |
| 15 Minute | 0 | 0 | 8 | 0 | 0 | 0 | 358 |
| Current | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 3 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 5 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 6 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 7 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 8 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 9 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 10 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 11 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 12 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 13 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Quarter 14 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| More <CR> | | | | | | | |
| ----- | | | | | | | |
| <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | | | | | | | |

View the performance monitor data for the selected interval 1 day:

| SHDSL NTU | | | | | | | |
|---|-------|-----|-----|------|----|-----|-----|
| ----- | | | | | | | |
| Local | SHDSL | | | | E1 | | |
| | ES | SES | UAS | LOSW | ES | SES | UAS |
| 24 Hour | 0 | 0 | 34 | 0 | 0 | 0 | 659 |
| Current | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 1 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 2 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 3 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 4 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 5 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 6 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Day 7 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| Press any key to Return Menu Window..._ | | | | | | | |
| ----- | | | | | | | |
| <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | | | | | | | |

For **Serial and Ethernet Interface model**, there have only SHDSL item.

View the performance monitor data for the selected interval 15 minutes:

| SHDSL NTU | | | | |
|---|-------|-----|-----|------|
| ----- | | | | |
| Local | SHDSL | | | |
| ----- | | | | |
| 15 Minute | ES | SES | UAS | LOSW |
| Current | 0 | 0 | 37 | 0 |
| Quarter 1 | 0 | 0 | 0 | 0 |
| Quarter 2 | 0 | 0 | 0 | 0 |
| Quarter 3 | 0 | 0 | 0 | 0 |
| Quarter 4 | 0 | 0 | 0 | 0 |
| Quarter 5 | 0 | 0 | 0 | 0 |
| Quarter 6 | 0 | 0 | 0 | 0 |
| Quarter 7 | 0 | 0 | 0 | 0 |
| Quarter 8 | 0 | 0 | 0 | 0 |
| Quarter 9 | 0 | 0 | 0 | 0 |
| Quarter 10 | 0 | 0 | 0 | 0 |
| Quarter 11 | 0 | 0 | 0 | 0 |
| Quarter 12 | 0 | 0 | 0 | 0 |
| Quarter 13 | 0 | 0 | 0 | 0 |
| Quarter 14 | 0 | 0 | 0 | 0 |
| More <CR> | | | | |
| ----- | | | | |
| <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | | | | |

View the performance monitor data for the selected interval 1 day:

| SHDSL NTU | | | | |
|---|-------|-----|-----|------|
| ----- | | | | |
| Local | SHDSL | | | |
| | ----- | | | |
| 24 Hour | ES | SES | UAS | LOSW |
| Current | 0 | 0 | 80 | 0 |
| Day 1 | 0 | 0 | 0 | 0 |
| Day 2 | 0 | 0 | 0 | 0 |
| Day 3 | 0 | 0 | 0 | 0 |
| Day 4 | 0 | 0 | 0 | 0 |
| Day 5 | 0 | 0 | 0 | 0 |
| Day 6 | 0 | 0 | 0 | 0 |
| Day 7 | 0 | 0 | 0 | 0 |
| | | | | |
| Press any key to Return Menu Window... | | | | |
| ----- | | | | |
| <I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom | | | | |

If you want to show the remote side's statistics, please use the Rmt-statistics function as the following.

```

                                SHDSL NTU
-----
Shdsl          Show SHDSL Status
Interface      Show Interface Status
Current Perf   Show Current Performance
Loc_statistics Show Local Statistics
>> Rmt_statistics Show Remote Statistics
clear          Clear Channel Statistics

-----

Command:Rmt_statistics <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

The following are commonly used acronyms:

| | |
|-------------|---|
| ES | Number of error seconds in which one or more CRC (Cyclic Redundancy Check) error events occurred during the current interval. This value is updated every time. |
| UAS | Number of unavailable seconds in which a failed signal occurred during the current interval. This value is updated every time. |
| SES | Number of severely errored seconds in which 832 or more CRC error events occurred during the current interval. This value is updated every time. |
| LOSW | Number of seconds with loss of sync word during the current interval. This value is updated every time. |

4.6.5 Clear Channel Statistics

If you want clear the statistics log data, please select clear command and choose **Local**, **Remote** or **Both side** to clear.

```
SHDSL NTU
-----
Shdsl          Show SHDSL Status
Interface      Show Interface Status
Current Perf   Show Current Performance
Loc_statistics Show Local Statistics
Rmt_statistics Show Remote Statistics
>> clear       Clear Channel Statistics

-----
Command:clear <CR>
Message: Please input the following information.
Input the channel to clear (TAB Select) <Local>: Local_

-----
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.7 [Show] View System Configuration

By using show command, you can view the system configuring. Select **show** and press [ENTER] or [RIGHT].

```

                                SHDSL NTU
-----
  setup          Configure system
  status         Show running system status
>> show         View system configuration
  reboot        Reset and boot system
  diag          Diagnostic utility
  upgrade        Console software upgrade
  exit           Quit system

-----

Command:show <more...> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.7.1 Show general Interface

To show system information, please select **system** and press [ENTER] or [RIGHT]. The screen will prompt the system information.

```

SHDSL NTU
-----
>> System          Show General Information
   Config          Show Configuration
   Script          Show Configuration in Command Script

-----

Command: System <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

The cursor is already on the **System** command, so press ENTER and the following screen will display the general system information.

```

SHDSL NTU
-----
<System Info Window>
      Local Side                      Remote Side
      =====                      =====
Model      :          5030G V2                5030G V2
Sw Version :          0.33                    0.33
FPGA Version :          0.10                  0.10
CPU        :      Winbond W90N740            Winbond W90N740
RAM        :          8MB                    8MB
FLASH      :          2MB                    2MB
Dsp Version :          R3.1.1                R3.1.1
SerialNo   :      BKLM1234ABCD                BKLM1234ABCD
System MCSV : 1537-0000-10011244            1537-0000-10011244
Kernel MCSV : 1537-0012-03313AE1            1537-0012-03413AE3
FPGA MCSV  : 1388-0012-01013ADE            1388-0012-01013ADE
System Live Time : 0 Day/ 0Hour/ 48Min /44 Secs

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom

```

Most of the information on this screen is either self explanatory or it is simply irrelevant for the end user. However, two items, the Kernel (SW Version) and FPGA (Field Programmable Gate Array) version will give the software and hardware versions respectively of NTU. These are important to know in case new firmware becomes available in the future to add extra functions or to fix unknown bugs from the original manufactured equipment.

4.7.2 Show configuration in listing format

To show the system configuration, please select **Config** and press [ENTER] or [RIGHT]. The screen will prompt the all configuration data.

For E1 interface model:

```
SHDSL NTU
-----
Showing System Configuration...
setup NTU Interface      :      E1
setup NTU Type           :      STU-R
setup Shdsl Annex        :      Annex-B
setup Shdsl Psd          :      SYM
setup Shdsl Margin       :      21
setup Shdsl Power BackOff :      Disable
setup E1 Channel         :      FULL
setup E1 Slot Number     :      32
setup E1 First Slot      :      1
setup E1 Code            :      HDB3
setup E1 AIS             :      Off
setup E1 Build Outs      :      120 Ohm
Press any key to Return Menu Window...
```

For Serial interface model:

```
SHDSL NTU
-----
Showing System Configuration...
setup NTU Interface      :      Serial
setup NTU Type           :      STU-R
setup Shdsl Annex        :      Annex-B
setup Shdsl Psd          :      SYM
setup Shdsl Margin       :      21
setup Shdsl Power BackOff :      Disable
setup Serial Interface    :      V35
setup Serial Data Rate    :      32
setup Serial Clock        :      normal
setup Serial Rts          :      on
setup Serial Cts          :      from_rts
setup Serial Dsr          :      on
setup Serial Dcd          :      from_dsl
setup Serial Delay        :      3
Press any key to Return Menu Window..._
```

For Ethernet interface model:

```

                                SHDSL NTU
-----
Showing System Configuration...
setup NTU Interface      :      Ethernet
setup NTU Type           :      STU-R
setup Shdsl Annex        :      Annex-B
setup Shdsl Psd          :      SYM
setup Shdsl Margin       :      21
setup Shdsl Power BackOff :      Disable
setup Ethernet Auto Config :      Enable
setup Ethernet Speed     :      100M
setup Ethernet Duplex    :      Full-Duplex
setup Ethernet Rate      :      36
Press any key to Return Menu Window..._
```

For E1 and Serial interface model:

```

                                SHDSL NTU
-----
Showing System Configuration...
setup NTU Interface      :      E1 Serial
setup NTU Type           :      STU-R
setup Shdsl Annex        :      Annex-B
setup Shdsl Psd          :      SYM
setup Shdsl Margin       :      21
setup Shdsl Power BackOff :      Disable
setup E1 Channel         :      PCM31
setup E1 Slot Number     :      24
setup E1 First Slot      :      1
setup E1 Code            :      HDB3
setup E1 AIS             :      Off
setup E1 Build Outs      :      120 Ohm
setup Serial Interface   :      V35
setup Serial Data Rate   :      32
setup Serial Clock       :      normal
setup Serial Rts         :      on
setup Serial Cts         :      from_rts
setup Serial Dsr         :      on
setup Serial Dcd         :      from_dsl
setup Serial Delay       :      3
Press any key to Return Menu Window..._
```

For E1 and Ethernet interface model:

```
SHDSL NTU
-----
Showing System Configuration...
setup NTU Interface      : E1 Ethernet
setup NTU Type          : STU-R
setup Shdsl Annex       : Annex-B
setup Shdsl Psd         : SYM
setup Shdsl Margin      : 21
setup Shdsl Power BackOff : Disable
setup E1 Channel        : PCM31
setup E1 Slot Number    : 24
setup E1 First Slot     : 1
setup E1 Code           : HDB3
setup E1 AIS            : Off
setup E1 Build Outs     : 120 Ohm
setup Ethernet Auto Config : Enable
setup Ethernet Speed    : 100M
setup Ethernet Duplex   : Full-Duplex
setup Ethernet Rate     : 36
Press any key to Return Menu Window..._
```

4.7.3 Show configuration in command script

To show the system script file, please select **Script** and press [ENTER] or [RIGHT]. The screen will prompt the configuration in script type.

```
SHDSL NTU
-----
System          Show General Information
Config          Show Configuration
>> Script       Show Configuration in Command Script

-----

Command:Script <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

For E1 interface model:

```
SHDSL NTU
-----
<Script Window>

setup mode STU-R
setup Shdsl Interface E1
setup Shdsl Annex Annex-B
setup Shdsl Psd SYM
setup Shdsl Margin 3
setup Shdsl Pwr Backoff Disable
setup E1 Channel FULL
setup E1 code HDB3
setup E1 ais Off
setup E1 build_outs 120 Ohm
Press any key to Return Menu Window..._
```


For Serial interface model:

```
-----
SHDSL NTU
-----
<Script Window>

setup mode STU-R
setup Shdsl Interface Serial
setup Shdsl Annex Annex-B
setup Shdsl Psd SYM
setup Shdsl Margin 3
setup Shdsl Pwr Backoff Disable
setup Serial Interface V35
setup Serial Data Rate 32
setup Serial Clock normal
setup Serial Rts on
setup Serial Cts from_rts
setup Serial Dsr on
setup Serial Dcd from_dsl
setup Serial Delay 3
Press any key to Return Menu Window..._
```

For Ethernet interface model:

```
-----
SHDSL NTU
-----
<Script Window>

setup mode STU-R
setup Shdsl Interface Ethernet
setup Shdsl Annex Annex-B
setup Shdsl Psd SYM
setup Shdsl Margin 3
setup Shdsl Pwr Backoff Disable
setup Ethernet Rate 36
setup Ethernet Auto Enable
setup Ethernet Duplex Full-Duplex
setup Ethernet Speed 100M
Press any key to Return Menu Window...
```

For E1 and Serial interface model:

```
-----SHDSL NTU-----
<Script Window>

setup mode STU-R
setup Shdsl Interface E1 Serial
setup Shdsl Annex Annex-B
setup Shdsl Psd SYM
setup Shdsl Margin 3
setup Shdsl Pwr Backoff Disable
setup E1 Channel PCM31 24 1
setup E1 code HDB3
setup E1 ais Off
setup E1 build_outs 120 Ohm
setup Serial Interface V35
setup Serial Data Rate 32
setup Serial Clock normal
setup Serial Rts on
setup Serial Cts from_rts
setup Serial Dsr on
setup Serial Dcd from_dsl
setup Serial Delay 3
Press any key to Return Menu Window..._
```

For E1 and Ethernet interface model:

```
-----SHDSL NTU-----
<Script Window>

setup mode STU-R
setup Shdsl Interface E1 Ethernet
setup Shdsl Annex Annex-B
setup Shdsl Psd SYM
setup Shdsl Margin 3
setup Shdsl Pwr Backoff Disable
setup E1 Channel PCM31 24 1
setup E1 code HDB3
setup E1 ais Off
setup E1 build_outs 120 Ohm
setup Ethernet Rate 36
setup Ethernet Auto Enable
setup Ethernet Duplex Full-Duplex
setup Ethernet Speed 100M
Press any key to Return Menu Window..._
```

4.8 [Reboot] Reboot the system

In main menu, move the cursor to **reboot** and press [ENTER]. The device will reboot after confirming.

```
SHDSL NTU
-----
  setup      Configure system
  status     Show running system status
  show       View system configuration
>> reboot   Reset and boot system
  diag       Diagnostic utility
  upgrade    Console software upgrade
  exit       Quit system

-----

Command:reboot <CR>
Message: Please input the following information.

Do you want to reboot? (y/n): y_

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

After the reboot operation have finished, RAM test are starting again.

```
SHDSL NTU
-----
  setup      Configure system
  status     Show running system status
  show       View system configuration
>> reboot   Reset and boot system
  diag       Diagnostic utility
  upgrade    Console software upgrade
  exit       Quit system

-----

Command:reboot <CR>
Message: Please input the following information.

Do you want to reboot? (y/n): y
00800000 Ram Ok

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.9 [Diag] Diagnostic – Loopback and BER Test

The diagnostic facility allows you to test the different aspects of your UM-SN VER.2 NTU to determine if it is working properly. Select **diag** and press [ENTER] .

```
SHDSL NTU
-----
  setup          Configure system
  status         Show running system status
  show           View system configuration
  reboot         Reset and boot system
>> diag         Diagnostic utility
  upgrade        Console software upgrade
  exit           Quit system

-----

Command:diag <more...>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

4.9.1 Loopback test

Loopback can test whether the NTU is properly worked with the connection device.

Press [ENTER] or [RIGHT] to setup the loopback.

```
SHDSL NTU
-----
>> Loopback          Execute Loopback
   BerTest           Execute Local Ber Test

-----

Command:Loopback <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The loopback screen is as following:

```
SHDSL NTU
-----
>> Loopback          Execute Loopback
   BerTest           Execute Local Ber Test

-----

Command:Loopback <CR>
Message: Please input the following information.

Change Loopback (TAB Select) <Disable>: Local Digital

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

For more information about those loopback functions, please refer the Keypads and LCD setting chapter.

4.9.2 BER Test

The product supports Bit Error Rate Testing (BERT). To configure the BERT, move the cursor to BerTest and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
>> Loopback          Execute Loopback
    BerTest          Execute Local Ber Test

Command:BerTest <CR> _
Message:

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The BER Test screen is as following:

```
SHDSL NTU
-----
Monitoring Window...BER Test

Test Pattern      :      2047
Time Elapsed      :      101
Pattern Sync      :      Sync
Bit Error Count   :      275

Refresh counter:51, Press 'Ctrl+C' to quit..._

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

The UM-SN VER.2 NTU includes an internal Bit Error Rate Tester (BERT) for complete testing of local and remote modem and the link quality without any need for external test equipment. This built-in Bit Error Rate Test generator can generates a standard 2047 ($2^{11}-1$) test pattern (Pseudorandom test pattern, 2047 bits in length).

| | |
|-------------------|---|
| Test Pattern 2047 | Use the standard 2047 ($2^{11}-1$) test |
| Time Elapsed | pattern |
| Pattern Framing | Show the time elapsed count |
| Bit Error Count | Show the linking is sync or no sync |
| Refresh counter | Show the bit error counter |
| | Page refresh counter |

You can press CTRL-C to quit this page anytime.

4.10 [Upgrade] firmware upgrade

This section will introduce how to upgrade the kernel and FPGA code of UM-SN VER.2 NTU. Select **upgrade** in main menu and press [ENTER] or [RIGHT].

Please notice that when you use Remote Upgrade feature. It means you can use those feature to update firmware to remote side. It will describe below.

During on upgrade and re-flash, the normal transmissions will be halted, so the upgrade should be done when the system is taken offline or done during a time of extremely low impact to the customer's line.

The upgrade process uses the Xmodem protocol via the rear panel's serial console port.

Following show the upgrade feature:

```
SHDSL NTU
-----
  setup      Configure system
  status     Show running system status
  show       View system configuration
  reboot     Reset and boot system
  diag       Diagnostic utility
>> upgrade  Console software upgrade
  exit       Quit system
-----

Command:upgrade <more...> _
Message:

-----
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Before upgrading the SHDSL NTU, make sure you have the Kernel code and FPGA code files in your computer.

When you upgrade the kernel code, select the **Kernel** item and press [ENTER] or [RIGHT].


```
SHDSL NTU
-----
>> Kernel          Upgrade main software
    Fpga            Upgrade FPGA code
    Rmt Kernel      Upgrade the remote's main software
    Rmt FPGA        Upgrade the remote's FPGA code

-----

Command:Kernel <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Click Send file in terminal access program, hyper terminal, to send the file. Make sure the sending protocol is **Xmodem**. Select the source file in window and press OK.

When it was upgrading, you can see as following:

```
SHDSL NTU
-----

Starting XModem Upload...CCCCCCC

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

If you want to upgrade the FPGA code, select **FPGA** item and press [ENTER] or [RIGHT].

```
SHDSL NTU
-----
Kernel          Upgrade main software
>> Fpga         Upgrade FPGA code
Rmt Kernel      Upgrade the remote's main software
Rmt FPGA        Upgrade the remote's FPGA code

-----

Command:Fpga <CR>
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

When it was upgrading, you can also see as following:

```
SHDSL NTU
-----

Starting XModem Upload...CCCCCCC

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

SHDSL NTU

```
-----  
Starting XModem Upload...CCCCCCCCCCCCCCCCCCCCCCCCCCCCCCCC  
EraseFlash Now.....  
Starting to write flash.....  
Do you want to reboot? (y/n):_
```

```
-----  
<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Once the upgrade is complete, there required to male the final confirmation to erase and re-write the flash with new code. After the upgrade produces is finish, you can reboot the system starting to use the new firmware version.

If the local side and remote side have connected, you can use the remote side firmware upgrade function.

Below showed is the remote upgrade feature:

Remote upgrade - Kernel

```

                                SHDSL NTU
-----
Kernel      Upgrade main software
Fpga        Upgrade FPGA code
>> Rmt Kernel Upgrade the remote's main software
Rmt FPGA    Upgrade the remote's FPGA code

-----

Command:Rmt Kernel <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Remote upgrade - FPGA

```

                                SHDSL NTU
-----
Kernel      Upgrade main software
Fpga        Upgrade FPGA code
Rmt Kernel  Upgrade the remote's main software
>> Rmt FPGA Upgrade the remote's FPGA code

-----

Command:Rmt FPGA <CR> _
Message:

-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

Before upgrading the NTU, you must have the Kernel code file and FPGA code file in your computer.

WARNING!!: Do not allow any interruption of power during the erase and re-write operation or the Flash will be left in an unknown state and the device will no longer be able to function. The device must then be returned to the factory for repair.

4.11 [Exit] Exit the system

For exiting the system, you can use **exit** command to exit. Select **exit** in main menu and press [ENTER] or [RIGHT]. Answer y(es) to confirm.

```
SHDSL NTU
-----
  setup          Configure system
  status         Show running system status
  show           View system configuration
  reboot         Reset and boot system
  diag           Diagnostic utility
  upgrade        Console software upgrade
>> exit         Quit system

-----

Command:exit <CR>
Message:


-----

<I/K> Move up/down, <J/L> Exit/Enter, <U/O> Move top/bottom
```

After press [ENTER], they will be disconnected.

```
Connection closed...
Press Space key to enter console mode configuration!
```

When it have disconnected, we can see the close screen. You can press Space key to restart the display.



```
User: admin
Password: *****_
```

The new login screen will show again, you can type username and password again to re-enter this system.

5 Appendix

5.1 Abbreviation

| | |
|------|---|
| AIS | Alarm Indication Signal |
| AMI | Alternate mark inversion |
| ASYM | Asymmetric |
| ATM | Asynchronous Transfer Mode |
| B8ZS | Bipolar with 8 zero substitution |
| BER | Bit error rate |
| BERT | Bit Error Rate Tester |
| BNC | Bayonet Nut Coupling Bayonet Neill-Concelman Barrel Nut Connector Bayonet Nipple Connector Bayonet Navy Connector Baby N Connector |
| bps | Bits per second |
| CAS | Channel Associated Signaling |
| CEPT | European Conference of Postal and Telecommunications Administrations. |
| CERR | CRC Errors |
| CO | Central Office |
| CPE | Customer Premises Equipment |
| CPU | Central processing unit |
| CRC | Cyclic redundancy check |
| CRC4 | Cyclic redundancy check 4 bit |
| CRS | Carrier Sense |
| CSU | Channel service unit |
| CTS | Clear to send |
| DCD | Data carrier detect |
| DCE | Data communication equipment |
| DSL | Digital subscriber loop |
| DSR | Data set ready |

| | |
|-----------|---|
| DSLAM | DSL Access Multiplexer |
| DTE | Data terminal equipment |
| DTR | Data terminal ready |
| E BIT GEN | Remote End Block Error Bit generation |
| EOC | Embedded operations channel |
| ES | Number of Error second (Errors/Second) |
| ESF | Extended super frame |
| ETSI | European Telecommunications Standardization Institute |
| FAS | Frame alignment signal |
| FCS | Frame Check Sequence |
| HDB3 | High-Density Bipolar of order 3 |
| HDLC | High-Level Data Link Control |
| HEC | Header error check |
| I/F | Interface |
| ITU | International Telecommunication Union |
| ITU-T | ITU-Telecommunication Standardization Sector |
| LBO | Line Build Out |
| LIU | Line Interface Unit |
| LOC | Loss of Connection |
| LOF | Loss of frame |
| LOS | Loss of signal |
| LOSW | Loss of synchronization word |
| LTU | Line Termination Unit |
| MAS | Multi-frame Alignment Sequence (CAS Format) |
| MFAS | Multi-frame Alignment Sequence (CRC4 Format) |
| MHz | Megahertz |
| NI | Network Interface |
| NRZ | Non-Return to Zero |
| NTU | Network Termination Unit |
| PABX | Private Automatic Branch Exchange |
| PAM | Pulse Amplitude Modulation |
| PLL | Phase-locked loop |
| POTS | Plain Old Telephone Service |
| PRBS | Pseudo-Random Bit Sequence |
| PSD | Power spectral density |
| QRSS | Quasi-Random Signal Source |
| RAI | Remote alarm indication |
| RESYNC | Resynchronization |


| | |
|--------------|---|
| RJ-45 | Registered Jack-45 |
| RTS | Request to send |
| RX | Receiver |
| SES | Number of Severely error seconds (more than 832 CRC errors / second. Approximately equivalent to a bit error rate of 1×10^{-3}) |
| SDLC | Synchronous data Link Control |
| SF | Super Frame |
| SHDSL | Symmetric High-Bitrate Digital Subscriber Loop |
| SLC | Subscriber Loop Carrier |
| SMF | Sub-Multi frame |
| SNA | System Network Architecture |
| SNR MARGIN | Signal to noise ration margin |
| STU | SHDSL Terminal Unit |
| STU-C | SHDSL Terminal Unit - Central office side |
| STU-R | SHDSL Terminal Unit - Remote side |
| STU-C-INTCLK | STU-C internal clock |
| STU-R-EXTCLK | STU-R external clock |
| SYM | Symmetric |
| SYNC | Synchronization |
| TC-PAM | Trellis Coded Pulse Amplitude Modulation |
| TDM | Time Division Multiplexing |
| TPS-TC | Transmission Protocol Specific TC layer |
| TX | Transmitter |
| Tx Power | Transmission power |
| UAS | Unavailable second |
| UI | User interface |
| WAN | Wide Area Network |
| xDSL | "Any" DSL , (ADSL , HDSL ,SHDSL or VDSL etc) |

5.2 Serial Interface Pin Assignments

The table below displays Serial Interface Pin Assignments for the DCE Mode

| Function | Abbrev. | Direction | RS-530 DB-25(F) | V.35 M.34(F) | X.21 DB-15(F) |
|--------------------------------------|---------|-----------|--------------------|-----------------|------------------|
| Frame Ground | FG | N/A | 1 | A | 1 |
| Transmit Data | TD | Input | 2 | P | 2 |
| Receive Data | RD | Output | 3 | R | 4 |
| Request to Send | RTS | Input | 4 | C | 3 |
| Clear to Send | CTS | Output | 5 | D | |
| Data Set Ready | DSR | Output | 6 | E | |
| Signal Ground | SG | N/A | 7 | B | 8 |
| Data Carrier Detect | DCD | Output | 8 | F | 5 |
| Secondary Receiver Clock | (S)RC | Output | 9 | X | 13 |
| Secondary Data Carrier Detect | (S)DCD | Output | 10 | | 12 |
| Secondary External Transmitter Clock | (S)ETC | Input | 11 | W | 7 |
| Secondary Transmitter Clock | (S)TC | Output | 12 | AA | |
| Secondary Clear to Send | (S)CTS | Output | 13 | | |
| Secondary Transmit Data | (S)TD | Input | 14 | S | 9 |
| Transmitter Clock | TC | Output | 15 | Y | |
| Secondary Receive Data | (S)RD | Output | 16 | T | 11 |
| Receiver Clock | RC | Output | 17 | V | 6 |
| Local Loopback | | | 18 | | |
| Secondary Request to Send | (S)RTS | Input | 19 | | 10 |
| Data Terminal Ready | DTR | Input | 20 | H | |
| Remote Loopback | | | 21 | | |
| Secondary Data Set Ready | (S)DSR | Output | 22 | | |
| Secondary Data Terminal Ready | (S)DTR | Input | 23 | | |
| External Transmitter Clock | ETC | Input | 24 | U | 14 |
| Test Indicator | | | 25 | | |

The front view of DB-25(F) Serial interface connector on rear panel:




5.3 V.35 DB25(M) to M.34(F) adaptor Cable

If the DTE (Data Terminal Equipment) connector is using 34-pin Winchester type, we must use the cable adaptor from DB-25 to Winchester (M.34).

The pin out of cable on DB-25(male) Connector to M.34(female) Connector

| DB-25 Pin | Signal | M.34 Pin | Description |
|-----------|--------|----------|---------------------|
| 2 | TD | P | Transmit Data |
| 14 | TD | S | Transmit Data |
| 3 | RD | R | Receive Data |
| 16 | RD | T | Receive Data |
| 4 | RTS | C | Ready To Send |
| 5 | CTS | D | Clear To Send |
| 6 | DSR | E | Data Set Ready |
| 20 | DTR | H | Data Terminal Ready |
| 24 | XTC | U | DTE Transmit Clock |
| 11 | XTC | W | DTE Transmit Clock |
| 15 | TC | Y | Transmit Clock |
| 12 | TC | AA | Transmit Clock |
| 17 | RC | V | Receive Clock |
| 9 | RC | X | Receive Clock |
| 1 | FGND | A | Protective Ground |
| 7 | GND | B | Signal Ground |
| 8 | DCD | F | Data Carrier Detect |

The front view of DB-25(M) connector and V.35(F) connector on this cable:



V.35 interface (34-pin Winchester type) contains the following signals:

| Pin | Signal | Abbr. | DTE | DCE |
|-----|---------------------|---------|-----|-----|
| A | Chassis Ground | FGND | --- | --- |
| B | Signal Ground | GND | --- | --- |
| C | Request To Send | RTS | Out | In |
| D | Clear To Send | CTS | In | Out |
| E | Data Set Ready | DSR | In | Out |
| F | Data Carrier Detect | DCD | In | Out |
| H | Data Terminal Ready | DTR | Out | In |
| J | Unassigned | | | |
| K | Unassigned | | | |
| L | Unassigned | | | |
| M | Unassigned | | | |
| N | Unassigned | | | |
| P | Send Data A | SD(A) | Out | In |
| R | Receive Data A | RD(A) | In | Out |
| S | Send Data B | SD(B) | Out | In |
| T | Receive Data B | RD(B) | In | Out |
| U | Terminal Timing A | SCTE(A) | Out | In |
| V | Receive Timing A | SCR(A) | In | Out |
| W | Terminal Timing B | SCTE(B) | Out | In |
| X | Receive Timing B | SCR(B) | In | Out |
| Y | Send Timing A | SCT(A) | In | Out |
| Z | Unassigned | | | |
| AA | Send Timing B | SCT(B) | In | Out |
| BB | Unassigned | | | |
| CC | Unassigned | | | |
| DD | Unassigned | | | |
| EE | Unassigned | | | |
| FF | Unassigned | | | |
| HH | Unassigned | | | |
| JJ | Unassigned | | | |
| KK | Unassigned | | | |
| LL | Unassigned | | | |
| MM | Unassigned | | | |
| NN | Unassigned | | | |

V.35 is a partially balanced, partially single-ended interface specification. The data leads and clock leads are balanced, the handshake leads are single-ended.

TD, RD, TC, RC and XTC are differential signals conforming to RS-422/V.11. Remaining signals are conformed to RS-232.

5.4 X.21 DB25(M) to DB15(F) adaptor Cable


For X.21 application, we must use the DB-25 to DB-15 adaptor cable for connects to a X.21 DTE DB-15 male cable.

The pin out of cable on DB-25(male) Connector to DB-15(Female) (X.21) Connector

| DB-25 Pin | Signal | DB-15 (X.21) Pin | Description |
|-----------|--------|------------------|---------------------|
| 1 | FGND | 1 | Protective Ground |
| 7 | GND | 8 | Signal Ground |
| 2 | T | 2 | Transmit Data |
| 14 | T | 9 | Transmit Data |
| 3 | R | 4 | Receive Data |
| 16 | R | 11 | Receive Data |
| 4 | C | 3 | Request To Send |
| 19 | C | 10 | Request To Send |
| 8 | I | 5 | Data Carrier Detect |
| 10 | I | 12 | Data Carrier Detect |
| 17 | S | 6 | Receive Clock |
| 9 | S | 13 | Receive Clock |

All signals are balanced. Meaning there is always a pair (+/-) for each signal, like used in RS422. The X.21 signals are the same as RS422, so please refer to RS422 for the exact details.

The front view of DB-25(M) connector and DB-15(F) connector on this cable:



The pin out of DB-15 connector on X.25 adaptor cable:


| Pin | Signal | Abbr. | DTE | DCE |
|-----|-------------------|-------|-----|-----|
| 1 | Shield | | | |
| 2 | Transmit (A) | TA | Out | In |
| 3 | Control (A) | CA | Out | In |
| 4 | Receive (A) | RA | In | Out |
| 5 | Indication (A) | IA | In | Out |
| 6 | Signal Timing (A) | SA | In | Out |
| 7 | Unassigned | | | |
| 8 | Ground | | | |
| 9 | Transmit (B) | TB | Out | In |
| 10 | Control (B) | CB | Out | In |
| 11 | Receive (B) | RB | In | Out |
| 12 | Indication (B) | IB | In | Out |
| 13 | Signal Timing (B) | SB | In | Out |
| 14 | Unassigned | | | |
| 15 | Unassigned | | | |

Functional Description:


The Signal Element Timing (clock) **(S)** is provided by the DCE. This means that the NTU is output the correct clocking and that X.21 is a synchronous interface. Hardware handshaking is done by the Control **(C)** and Indication **(I)** lines. The Control is used by the DTE and the Indication is the DCE one.

5.5 Console Cable


The front view of RJ-45 console cable socket on rear panel:




The wire connection of console cable DB-9(Female) to RJ-45:



The signal direction of console cable:




The pin assignment of RJ-45 modular jack on the console cable:

| Pin Number | Abbrev. | Description | Figure |
|------------|---------|-------------------------------|--|
| 1 | DSR | DCE ready |  <p>Top View</p> <p>Front View</p> |
| 2 | DCD | Received Line Signal Detector | |
| 3 | DTR | DTE ready | |
| 4 | GND | Signal Ground | |
| 5 | RXD | Received Data | |
| 6 | TXD | Transmitted Data | |
| 7 | CTS | Clear to Send | |
| 8 | RTS | Request to Send | |

5.6 E1 Balance Cable

The front view of RJ-48C E1 balance cable socket on rear panel:



The pin out of RJ-48C plug on the G.703 120Ω E1 balance cable:

| Pin Number | Description | Figure |
|------------|---------------------------------|---|
| 1 | E1 interface receive pair-ring | <p>Top View</p> <p>Front View</p> |
| 2 | E1 interface receive pair-tip | |
| 3 | No connection | |
| 4 | E1 interface transmit pair-ring | |
| 5 | E1 interface transmit pair-tip | |
| 6 | No connection | |
| 7 | No connection | |
| 8 | No connection | |

The pin out of cable on DB-15(female) Connector to RJ-48C Connector:


| DB15(Female) Pin Number | RJ-48C Pin number | Description |
|----------------------------|----------------------|---------------|
| 11 | 4 | Transmit Ring |
| 5 | 3 | Rx Shield |
| 9 | 1 | Receive Ring |
| 6 | 6 | TX Shield |
| 3 | 5 | Transmit Tip |
| 1 | 2 | Receive Tip |

5.7 E1 Unbalance Cable

Connections to the E1 BNC ports are made using a 75-ohm coaxial cable with a bayonet-style twist-lock BNC connector.

We do not provide the cable. It is widely available from other sources.

The front view of BNC sockets on rear panel:



The internal wiring between BNC sockets and RJ-48C:


| Signal Name | BNC Connectors | RJ-48C Connector |
|---------------|----------------------------|------------------|
| Transmit Tip | Center pin of Tx Connector | 5 |
| Transmit Ring | Shield of Tx Connector | 4 |
| Receive Tip | Center pin of Rx Connector | 2 |
| Receive Ring | Shield of Rx Connector | 1 |

5.8 Ethernet Cable

The Ethernet cables should be 4 pair unscreened cable (UTP) or screened (STP) of type CAT5 (or higher). Both crossed and normal wiring styles are supported by the auto-crossover feature of the NTU.

We do not provide the cable. It is widely available from other sources.

The front view of RJ-45 Ethernet cable socket on rear panel:




The pin out of RJ-45 Ethernet Connector:

| Pin number | Signal Name |
|------------|-----------------|
| 1 | Transmit Data + |
| 2 | Transmit Data - |
| 3 | Receive Date + |
| 4 | Not used |
| 5 | Not used |
| 6 | Receive Date - |
| 7 | Not used |
| 8 | Not used |


5.9 DSL Cable

The front view of DSL cable socket on rear panel:




The pin out of RJ-45 modular jack on DSL cable:

| Pin Number | Description | Figure |
|------------|---------------------|--------|
| 1 | No connection | |
| 2 | No connection | |
| 3 | LOOP 2 Input/Output | |
| 4 | LOOP 1 Input/Output | |
| 5 | LOOP 1 Input/Output | |
| 6 | LOOP 2 Input/Output | |
| 7 | No connection | |
| 8 | No connection | |



5.10 Power Cord

The front view of IEC-320 C6 type AC Inlet on rear panel:




The pin out of AC Inlet connector:

| Pin number | Description |
|------------|---|
| E | Earth conductor |
| L | Live, hot or active |
| N | conductor Neutral or identified conductor |

The socket of the power cord is using IEC-320 C5 type. This 3-conductor colloquially called “Mickey Mouse” or “Clover Leaf”.


The front view of C5 line socket of the power cord:




5.11 Illustration of Loopback connection device (E1)

| RJ-48C Pin number | Description |
|-------------------------|---------------|
| 4 | Transmit Ring |
| 3 | Rx Shield |
| 1 | Receive Ring |
| 6 | TX Shield |
| 5 | Transmit Tip |
| 2 | Receive Tip |

Make the short circuit/wiring with a RJ-45 module jack of the following:



The top view of RJ-45 module jack on short circuit/wiring:



5.12 Illustration of Loopback connection device (Serial)

| DB-25(M) Pin number | Signal | Description |
|---------------------------|--------|------------------------|
| 2 | TD(A) | Transmit Data |
| 14 | TD(B) | Transmit Data |
| 3 | RD(A) | Receive Data |
| 16 | RD(B) | Receive Data |
| 4 | RTS | Ready To Send |
| 5 | CTS | Clear To Send |
| 6 | DSR | Data Set Ready |
| 20 | DTR | Data Terminal Ready |
| 24 | XTC | DTE Transmit Clock |
| 11 | XTC | DTE Transmit Clock |
| 15 | TC(A) | Transmit Clock |
| 12 | TC(B) | Transmit Clock |
| 17 | RC(A) | Receive Clock |
| 9 | RC(B) | Receive Clock |
| 1 | FGND | Protective Ground |
| 7 | GND | Signal Ground |
| 8 | DCD | Data Carrier Detect |

Make the short circuit/wiring with a DB-25(male) connector of the following:

| |
|------------------|
| PIN2 ←----→PIN3 |
| PIN14←----→PIN16 |
| PIN4 ←----→PIN5 |
| PIN6 ←----→PIN20 |

The back side view of DB-15(male) connector on short circuit/wiring:

